



# ISUZU 3080-LE

## INDEX

<i>TROUBLE SHOOTING.....</i>	<i>3</i>
<i>PRELIMINARY CHECK.....</i>	<i>5</i>
<i>TROUBLE CODES.....</i>	<i>13</i>
<i>TEARDOWN.....</i>	<i>16</i>
<i>COMPONENT TEARDOWN.....</i>	<i>31</i>
<i>VALVE BODY.....</i>	<i>56</i>
<i>TRANSFER CASE.....</i>	<i>70</i>
<i>TRANSFER CASE VALVE BODY.....</i>	<i>78</i>
<i>THRUST BEARING LOCATION.....</i>	<i>84</i>
<i>ASSEMBLY.....</i>	<i>85</i>
<i>A340E, F, H AND 341E DIFFERENCES.....</i>	<i>109</i>

*CAUTION: ATSG service manuals are intended for use by professional, qualified technicians. Attempting repairs or service without the proper training, tools and equipment could cause injury to you or others and damage to the vehicle that may cause it not to operate properly.*

**AUTOMATIC TRANSMISSION SERVICE GROUP  
18639 S.W. 107 AVENUE  
MIAMI, FLORIDA 33157  
(305) 670-4161**

Copyright © ATSG 2000

January, 2000



*Updated  
July, 2003*

## **INTRODUCTION ISUZU AW30-80LE**

The AW30-80LE is a rear wheel drive, four speed, electronically controlled, fully automatic transmission. Internal components consist of a lock-up torque converter, oil pump, 5 multi-disc clutch packs, 1 brake band and three planetary gear sets. The valve body includes electronic solenoids for shift control that are controlled by a Transmission Control Unit (TCU). Shift control is determined by vehicle speed and throttle position sensor signals, that are constantly monitored by the TCU. Throttle cable is used for line pressure control.

**We thank ISUZU for the information and  
illustrations that have made this booklet possible.**

No part of any ATSG publication may be reproduced, stored in any retrieval system or transmitted in any form or by any means, including but not limited to electronic, mechanical, photocopying, recording or otherwise, without *written* permission of Automatic Transmission Service Group. This includes all text illustrations, tables and charts.

*The information and part numbers contained in this booklet have  
been carefully compiled from industry sources known for their  
reliability, but ATSG does not guarantee its accuracy.*

*Copyright © ATSG 1993*

**DALE ENGLAND**  
FIELD SERVICE CONSULTANT

**WAYNE COLONNA**  
TECHNICAL SUPERVISOR

**PETER LUBAN**  
TECHNICAL CONSULTANT

**JON GLATSTEIN**  
TECHNICAL CONSULTANT

**ROLAND ALVAREZ**  
TECHNICAL CONSULTANT

**GERALD CAMPBELL**  
TECHNICAL CONSULTANT

**JIM DIAL**  
TECHNICAL CONSULTANT

**ED KRUSE**  
TECHNICAL CONSULTANT

**GREGORY LIPNICK**  
TECHNICAL CONSULTANT

**DAVID CHALKER**  
TECHNICAL CONSULTANT

**JERRY GOTT**  
TECHNICAL CONSULTANT

**MIKE SOUZA**  
TECHNICAL CONSULTANT

**AUTOMATIC TRANSMISSION SERVICE GROUP  
18639 SW 107TH AVENUE  
MIAMI, FLORIDA 33157  
(305) 670-4161**







# SERVICE INFORMATION

## GENERAL TROUBLESHOOTING

Problem	Possible cause	Remedy
No. lock-up in 2nd, 3rd or OD	Electronic control faulty Valve body faulty Solenoid valve faulty Transmission faulty	Inspect electronic control Inspect valve body Inspect valve body Disassemble and inspect transmission
Harsh down-shift	Throttle cable out of adjustment Throttle cable and cam faulty Accumulator pistons faulty Valve body faulty Transmission faulty	Adjust throttle cable Inspect throttle cable and cam Inspect accumulator pistons Inspect valve body Disassemble and inspect transmission
No down-shift when coasting	Valve body faulty Solenoid valve faulty Electronic control faulty	Inspect valve body Inspect solenoid valve Inspect electronic control
Down-shift occurs too quickly or too late while coasting	Throttle cable out of adjustment Throttle cable faulty Valve body faulty Transmission faulty Solenoid valve faulty Electronic control faulty	Adjust throttle cable Inspect throttle cable Inspect valve body Disassemble and inspect transmission Inspect solenoid valve Inspect electronic control
No OD-3, 3-2 or 2-1 kickdown	Solenoid valve faulty Electronic control faulty Valve body faulty Throttle cable out of adjustment	Inspect solenoid valve Inspect electronic control Inspect valve body Adjust throttle cable
No engine braking in "2" or "L" range	Solenoid valve faulty Electronic control faulty Valve body faulty Transmission faulty	Inspect solenoid valve Inspect electronic control Inspect valve body Disassemble and inspect transmission
Vehicle does not hold in "P"	Manual linkage out of adjustment Parking lock pawl cam and spring faulty	Adjust linkage Inspect cam and spring
No 2H-4H, 4H-4L, 4L-4H or 4H-2H change gear position of transfer	Transfer linkage out of adjustment Electronic control faulty Transfer valve body faulty Transfer faulty	Adjust linkage Inspect electronic control Inspect valve body Disassemble and inspect transfer


**Service Information AW30-80LE**
**GENERAL TROUBLESHOOTING**

<b>Problem</b>	<b>Possible cause</b>	<b>Remedy</b>
Fluid discolored or smells burnt	Fluid contaminated Torque converter faulty Transmission faulty	Replace fluid Replace torque converter Disassemble and inspect transmission
Vehicle does not move in any forward range or reverse	Manual linkage out of adjustment Valve body or primary regulator faulty Park lock pawl faulty Torque converter faulty Converter drive plate broken Oil pump intake screen blocked Transmission faulty	Adjust linkage Inspect valve body Inspect park pawl Replace torque converter Replace drive plate Clean screen Disassemble and inspect transmission
Shift lever position incorrect	Manual linkage out of adjustment Manual valve and lever faulty Transmission faulty	Adjust linkage Inspect valve body Disassemble and inspect transmission
Harsh engagement into any drive range	Throttle cable out of adjustment Valve body or primary regulator faulty Accumulator pistons faulty Transmission faulty	Adjust throttle cable Inspect valve body Inspect accumulator pistons Disassemble and inspect transmission
Delayed 1-2, 2-3, or 3-OD up-shift, or down-shifts from 4-3, or 3-2 and shifts back to 4 or 3	Electronic control faulty Valve body faulty Solenoid valve faulty	Inspect electronic control Inspect valve body Inspect valve body
Slips on 1-2, 2-3 or 3-OD up-shift, or slips or shudders on acceleration	Manual linkage out of adjustment Throttle cable out of adjustment Valve body faulty Solenoid valve faulty Transmission faulty	Adjust linkage Adjust throttle cable Inspect valve body Inspect valve body Disassemble and inspect transmission
Drag, binding or tie-up on 1-2, 2-3, or 3-OD up-shift	Manual linkage out of adjustment Valve body faulty Transmission faulty	Adjust linkage Inspect valve body Disassemble and inspect transmission



## PRELIMINARY CHECK

### INSPECTION OF TRANSMISSION FLUID LEVEL

Set parking brake.

With the engine idling, move the shift lever through all positions from "P" to "L", then return to position "P"

Check to see if the level of fluid comes to "HOT" range on the dipstick gauge.

If the level of fluid is too low, replenish to bring it to maximum level in "HOT" range.

### INSPECTION OF FLUID CONDITION

If the ATF is black or smells burnt, replace it.

### INSPECTION AND ADJUSTMENT OF THROTTLE CABLE

- 1) Depress the accelerator pedal all the way and check that the throttle valve opens fully.

**Note:** If the valve does not open fully, adjust the accelerator link.

- 2) Fully depress the accelerator.
- 3) Loosen the adjustment nuts.
- 4) Adjust the cable housing so that the distance between the end of the boot and stopper on the cable is the standard.

	mm(in.)
Standard boot and cable stopper distance	0.8 – 1.5 (0.03 – 0.06)
Stroke	32.9 <sup>+1</sup> / <sub>0</sub> (1.30 <sup>+0.04</sup> / <sub>0</sub> )

- 5) Tighten the adjusting nuts.
- 6) Recheck the adjustments.



### ADJUSTMENT OF SHIFT LINKAGE

- 1) Loosen the nut on the shift linkage.
- 2) Push the shift lever fully rearward.
- 3) Return the lever two notches to the "NEUTRAL" position.
- 4) While holding the selector lightly toward the "R" range side, tighten the shift linkage nut.



## MANUAL SHIFTING TEST

**Note:** With this test, it can be determined whether the trouble lies within the electrical circuit or is a mechanical problem in the transmission.



### DISCONNECT ECT COMPUTER CONNECTOR

- 1) With the engine OFF, disconnect the ECT connector.

### INSPECT MANUAL DRIVING OPERATION

Check that the shift and gear positions correspond with the table below.

If the "L", "2" and "D" range gear positions are difficult to distinguish, do not perform the following road test.

- 1) While driving, shift through the "L", "2" and "D" ranges and back up again. Check that the gear change corresponds to the gear position.
- 2) While driving, shift through the "D", "2" and "L" ranges and back down again. Check that the gear change corresponds to the gear position.


If any abnormality is found in the above test, do not perform the stall, time lag or gear change tests.

Position	Transmission		
	"D" range	"2" range	"L" range
Gear	OD	3rd	1st

Transmission	
"R" range	"P" range
Reverse	Pawl Lock

Position	*Transfer		
	"2H" position	"4H" position	"4L" position
Gear	High Gear 2WD	High Gear 4WD	High Gear 4WD

\*: Reference



### CONNECT ECT COMPUTER CONNECTOR

- 1) With the engine off, connect the ECT computer connector.



## Service Information AW30-80LE

### STALL TEST

The object of this test is to check the overall performance of the transmission and engine by measuring the maximum engine speeds at the "D" and "R" ranges.

- Note:** (1) Perform the test at normal operation fluid temperature (50 – 80°C or 122 – 176°F).  
 (2) Do not continuously run this test longer than 5 seconds.

#### MEASURE STALL SPEED

- 1) Chock the four wheels.
- 2) Mount an engine tachometer.
- 3) Fully apply the parking brake.
- 4) Step down strongly on the brake pedal with your left foot.
- 5) Shift the transfer lever to the "2H" position.
- 6) Start the engine.
- 7) Shift into the "D" range. Step all the way down on the accelerator pedal with your right foot. Quickly read the highest engine rpm.

Stall speed	2400 ± 150 rpm
-------------	----------------

- 8) Perform the same test in the "R" range.

#### EVALUATION

- 1) If the engine speed is the same for both ranges but lower than the specified value:

- Engine output is insufficient.
- Stator one-way clutch is not operating properly.

**Note:** If more than 600 rpm below the specified value, the torque converter could be faulty.

- 2) If the stall speed in "D" range is higher than specified:


- Line pressure too low
- Forward clutch slipping
- No. 2 one-way clutch not operating properly
- OD one-way clutch not operating properly
- Transfer direct clutch slipping

- 3) If the stall speed in "R" range is higher than specified:

- Line pressure too low
- Direct clutch slipping
- No. 3 brake slipping
- OD one-way clutch not operating properly
- Transfer direct clutch slipping

- 4) If the stall speed in the "R" and "D" ranges are higher than specified:

- Line pressure too low
- Improper fluid level
- OD one-way clutch not operating properly
- Transfer direct clutch slipping





## TIME LAG TEST

If the shift lever is shifted while the engine is idling, there will be a certain time elapse or lag before the shock can be felt. This is used for checking the condition of the OD clutch, front clutch, rear clutch and No. 3 brake.

- Note:** (1) Perform the test at normal operation fluid temperature (50 — 80°C or 122 — 176°F).  
 (2) Be sure to allow a one minute interval between tests.  
 (3) Make three measurements and take the average value.

### MEASURE LAG TIME

- 1) Fully apply the parking brake.
- 2) Shift the transfer shift lever to the "2H" position.
- 3) Start the engine.

Check idling speed (A/C OFF)

"N" range	850 — 950 rpm
-----------	---------------

- 4) Shift the shift lever from "N" to "D" range. Using a stop watch, measure the time it takes from shifting the lever until the shock is felt.


Lag time	Less than 1.2 seconds
----------	-----------------------

- 5) In same manner, measure the time lag for "N" → "R".

Lag time	Less than 1.5 seconds
----------	-----------------------

### EVALUATION

- 1) If "N" → "D" time lag is longer than specified:
  - Line pressure too low
  - Forward clutch worn
  - OD one-way clutch not operating properly
- 2) If "N" → "R" time lag is longer than specified:
  - Line pressure too low
  - Direct clutch worn
  - No. 3 brake worn
  - OD one-way clutch not operating properly







## Service Information AW30-80LE

### PREPARATION

- 1) Warm up the transmission fluid.
- 2) Remove the transmission case test plug and mount the hydraulic pressure gauge.

Oil pressure gauge : J-29770

**Note:** Perform the test at normal operating fluid temperature (50 – 80°C or 122 – 176°F).

### HYDRAULIC TEST

#### MEASURE LINE PRESSURE


- 1) Fully apply the parking brake and chock the four wheels.
- 2) Start the engine and check idling rpm.
- 3) Shift into "D" range, step down strongly on the brake pedal with your left foot and, while manipulating the accelerator pedal with the right foot, measure the line pressures at the engine speeds specified in the table.
- 4) In the same manner, perform the test in "R" range.


Engine speed	Line pressure kg/cm <sup>2</sup> (psi, kPa)	
	"D" range	"R" range
Idling	3.7 – 4.3 (53 – 61, 363 – 422)	5.1 – 6.1 (73 – 87 500 – 598)
Stall	9.3 – 11.8 (132 – 168, 132 – 1158)	13.0 – 16.5 (185 – 235, 1275 – 1619)

- 5) If the measured pressures are not up to specified values, recheck the throttle cable adjustment and perform a retest.

#### EVALUATION

- 1) If the measured values at all ranges are higher than specified.
  - Throttle cable out of adjustment
  - Throttle valve defective
  - Regulator valve defective
- 2) If the measured values at all ranges are lower than specified:
  - Throttle cable out of adjustment
  - Throttle valve defective
  - Regulator valve defective
  - Oil pump defective
  - OD clutch defective
  - Transfer direct clutch defective (4H)
  - Transfer front drive clutch defective (4H)
  - Transfer low speed brake defective (4L)
- 3) If pressure is low in "D" range only:
  - "D" range circuit fluid leakage
  - Forward clutch defective
- 4) If pressure is low in "R" range only:
  - "R" range circuit fluid leakage
  - Direct clutch defective
  - No. 3 brake defective





## ROAD TEST

**Note:** Perform the test at normal operating fluid temperature (50 – 80°C or 122 – 176°F).

**Note:** The transmission shift points for the 2H, 4H and 4L transfer positions are different. Also, the OD gear and lock-up are canceled when 4L is engaged.





### “D” RANGE TEST IN “NORM”, AND POWER PATTERN RANGES

Shift into the “D” range and hold the accelerator pedal constant at the 50% and 100% throttle valve opening positions.

Push in one of the pattern selector buttons and check the following:

- 1) 1-2, 2-3, 3-OD and lock-up, up-shifts should take place, and shift points should conform to those shown in the automatic shift diagram.

**Note:** There is no OD up-shift or lock-up when the coolant temp. is below 70°C (158°F) or if there is a 10 km/h (6 mph) difference between the set cruise control speed and real speed.





### EVALUATION

- (1) If there is no 1 → 2 up-shift:
    - No. 2 solenoid is stuck
    - 1-2 shift valve is stuck
  - (2) If there is no 2 → 3 up-shift:
    - No. 1 solenoid is stuck
    - 2-3 shift valve is stuck
  - (3) If there is no 3 → OD up-shift (throttle valve opening 1/2):
    - 3-OD shift valve is stuck
  - (4) If the shift point is defective:
    - Throttle valve, 1-2 shift valve, 2-3 shift valve, 3-OD shift valve etc., are defective.
  - (5) If the lock-up is defective:
    - No. 3 solenoid is stuck
    - Lock-up relay valve is stuck
- 2) In the same manner, check the shock and slip at the 1 → 2, 2 → 3 and 3 → OD up-shifts.

### EVALUATION

If the shock is excessive:

- Line pressure is too high
- Accumulator is defective
- Check ball is defective



3) Run at "D" range lock-up or OD gear and check for abnormal noise and vibration.



**Note:** The check for the cause of abnormal noise and vibration must be made with extreme care as it could also be due to loss of balance in the propeller shaft, differential, the torque converter, etc. or insufficient bending, rigidity, etc. in the power train.

4) While running in "D" range, 2nd, 3rd gears and OD, check to see that the possible kick-down vehicle speed limits for 2 → 1, 3 → 1, 3 → 2, OD → 3 and OD → 2 kick-downs conform to those indicated on the automatic shift diagram.

5) Check for abnormal shock and slip at kick-down.

6) While running in "D" range, OD gear or "lock-up", shift to "2" and "L" ranges and check the engine braking effect at each of these ranges.

7) Also check to see that downshift is made from 3 → 2 or from O.D. to 3 and then to 2 immediately and that 2 → 1 downshift point is within the limits shown in the diagram when tested by releasing the accelerator pedal and shifting into position of "L" while driving in the third gear or in overdrive.



### Evaluation






(1) If there is no engine braking effect in the "2" range:

- Second coast (No. 1) brake is defective

(2) If there is no engine braking effect in the "L" range:

- First and reverse (No. 3) brake is defective
- Second coast (No. 1) brake is defective

(3) Also check to see that downshift is made from 3 → 2 or from O.D. to 3 and then to 2 immediately and that 2 → 1 downshift point is within the limits shown in the diagram when tested by releasing the accelerator pedal and shifting into "L" position while driving in the third gear or in overdrive.



### "2" RANGE TEST

Shift into "2" range and, while driving with the accelerator pedal held constantly at the specified point (throttle valve opening 50% and 100%), push in one of the pattern selectors (only for 4x4) and check on the following points.

- 1) At each of the above throttle openings, check to see that the 1 → 2 up-shift takes place and that the shift points conform to those shown on the automatic shift diagram.

**Note:** There is no OD and no lock-up in the "2" range.

- 2) While running in the "2" range and 2nd gear, release the accelerator pedal and check the engine's braking effect.
- 3) Check for 2 → 1 down-shift and abnormal noise at acceleration and deceleration, and for shock at up-shift and down-shift.
- 4) Make a kickdown from the second gear and check the limit of vehicle speeds at which kickdown from "2" to "1" takes place (4x2 only).

### "L" RANGE TEST

- 1) While running above 80 km/h (50 mph) in the "D" range, release your foot from the accelerator pedal and shift into the "L" range.

Then check to see that the 2 → 1 down-shift occurs at the specified point shown on the automatic shift diagram.

- 2) While running in the "L" range, check to see that there is no up-shift to 2nd gear.
- 3) While running in the "L" range, release the accelerator pedal and check the engine braking effect.
- 4) Check for abnormal noise during acceleration and deceleration.

### "R" RANGE TEST

Shift into the "R" range and, while starting at full throttle, check for slippage.



### "P" RANGE TEST

Stop the vehicle on a grade (more than 9%) and after shifting into the "P" range, release the parking brake. Then check to see that the parking lock pawl holds the vehicle in place.




## Service Information AW30-80LE

### TRANSFER TEST



- 1) When the shift lever is shifted from "2H" to "4H", confirm that the vehicle changes from 2 to 4 wheel drive. If it does not, the transfer is faulty.
- 2) When the transfer lever is shifted from "4H" to "4L", confirm that the gear changes according to the shift diagram. If it does not, the No. 4 solenoid, ECT computer or transfer may be faulty.

Code No.	Light Pattern	Diagnosis System
21		Defective No. 1 speed sensor (in combination meter) — severed wire harness or short circuit
22		Defective No. 2 speed sensor (in Automatic transmission) — severed wire harness or short circuit
23		Severed throttle sensor or short circuit — Severed wire harness or short circuit
31		Severed No. 1 solenoid or short circuit — severed wire harness or short circuit
32		Severed No. 2 solenoid or short circuit — severed wire harness or short circuit
33		Severed No. 3 solenoid or short circuit — severed wire harness or short circuit
34		Severed No. 4 solenoid or short circuit — severed wire harness or short circuit



**Note:** If codes 31, 32, 33 or 34 appear, there is an electrical malfunction in the solenoid. Causes due to mechanical failure, such as a stuck switch, will not appear.






- Note:**
- Cancellation can also be done by removing the battery negative (-) terminal, but in this case other memory systems (ECM diagnosis memory, etc.) will also be canceled out.
  - The diagnostic code can also be canceled out by disconnecting the ECT computer connector.
  - If the diagnostic code is not cancelled out, it will be retained by the ECT computer and appear along with a new code on event of future trouble.
2. After cancellation, perform a road test to confirm that a "normal code" is now read on the OD "OFF" light.

### CANCEL OUT DIAGNOSTIC CODE

1. After repair of the trouble area, the diagnostic code retained in memory by the ECT computer must be canceled by removing the fuse No. 6 ECT CLOCK (10A) for 10 seconds or more, depending on ambient temperature (the lower the temperature, the longer the fuse must be left out) with the ignition switch off.



## Service Information AW30-80LE



### READING DIAGNOSTIC CODE

#### TURN IGNITION SWITCH AND OD SWITCH TO ON

Do not start the engine.

**Note:** Warning and diagnostic code can be read only when the overdrive switch is ON. If Off the overdrive light will light continuously and will not blink.

#### SHORT DG TERMINAL CIRCUIT

Using a service wire, short the DG terminal and body ground.

#### READ DIAGNOSTIC CODE

Read the diagnostic code as indicated by the number of times the OD "OFF" light flashes.

#### DIAGNOSTIC CODE

- 1) If the system is operating normally, the light will blink 2 times per second.





- 2) In the event of a malfunction, the light will blink once a second. The number of blinks will equal the first number and, after 1.5 second pause, the second number of the two digit diagnostic code. If there are two or more codes, there will be a 2.5 second pause between each.

**Note:** In the event of several trouble codes occurring simultaneously, indication will begin from the smaller value and continue to the larger.

- 3) Remove the service wire from the DG terminal.



**Service Information AW30-80LE**



DG Terminal (V)	Gear position
0	1st
2	2nd
3	2nd Lock-up
4	3rd
5	3rd Lock-up
6	OD
7	OD Lock-up

**INSPECT DG TERMINAL VOLTAGE**

**INSPECT THROTTLE POSITION SENSOR SIGNAL**

- 1) Turn the ignition switch to ON. Do not start the engine.
- 2) Connect a voltmeter to the DG terminal and body ground.
- 3) While slowly depressing the accelerator pedal, check that DG terminal voltage rises in sequence.

If the voltage does not change in proportion to the throttle opening angle, there is a malfunction in the throttle position sensor or circuit.

**INSPECT BRAKE SIGNAL**

- 1) Depress the accelerator pedal until the DG terminal indicates 8V:
- 2) Depress the brake pedal and check the voltage reading from the DG terminal.  
 Brake pedal depressed ..... 0V  
 Brake pedal released ..... 8V


If not as indicated, there is a malfunction in either the stop light switch or circuit.

**INSPECT EACH UP SHIFT POSITION**

- 1) Warm up the engine.  
Coolant temperature : 80°C (176°F)
- 2) Turn the OD switch to "ON".
- 3) Place the pattern select switch in "Normal" and the shift selector into the "D" range.
- 4) During a road test (above 10 km/h or 6 mph) check that voltage at the DG terminal is as indicated below for each up-shift position.
- 5) If the voltage rises from 0V to 7V in the sequence shown, the control system is okay.
- 6) Take the voltage reading when the vehicle speed is 10 km/h (6 mph) or more. The chart on the left shows the voltmeter reading and corresponding gears.


**Note:** Determine the gear position by a light shock or change in engine rpm when shifting. The lock-up clutch will turn ON only infrequently during normal 2nd and 3rd gear operation. To trigger this action, press the accelerator pedal to 50% or more of its stroke. At less than 50%, the voltage may change in the sequence 2V - 4V - 6V - 7V.

## DISASSEMBLY OF MAJOR COMPONENTS (1)



### Disassembly steps

- |                                     |                         |
|-------------------------------------|-------------------------|
| 1. Torque converter                 | 4. Neutral start switch |
| 2. Wire harness                     | 5. Union                |
| 3. Transmission control shaft lever | 6. Thermo sensor        |




### Wire harness

Remove wire harness clamp and throttle cable clamp







**Service Information AW30-80LE**




**Transmission control shaft lever**  
 Remove the transmission control shaft lever



**Neutral start switch**  
 Unstake the lock washer.  
 Remove the nut and bolts, and then remove the neutral start switch.  
 Remove the lock washer and grommet.




**Union**  
 Remove two unions from transmission case.



**Thermo sensor**  
 Remove a thermo sensor from right side of transmission case.  
 Remove a thermo sensor from right side of transfer chain case.

## DISASSEMBLY OF MAJOR COMPONENTS (2)




### Disassembly steps


- |                               |                                    |
|-------------------------------|------------------------------------|
| 1. Transfer position switch   | 15. Transfer chain case            |
| 2. Speed sensor               | 16. Front output shaft             |
| 3. Chain case oil cooler pipe | 17. Snap ring                      |
| 4. Oil pan                    | 18. Transfer drive clutch (C-4)    |
| 5. No. 4 solenoid             | 19. Snap ring                      |
| 6. Transfer valve body        | 20. Snap ring                      |
| 7. Parking lock pawl bracket  | 21. Transfer center support        |
| 8. Companion flange           | 22. Transfer low speed brake (B-4) |
| 9. Front companion flange     | 23. Sun gear and bearing           |
| 10. Extension housing         | 24. Snap ring and bearing          |
| 11. Speedometer drive gear    | 25. Transfer direct clutch         |
| 12. Transfer chain case cover | 26. Transfer front support         |
| 13. Snap ring                 | 27. Transfer case                  |
| 14. Sprocket and driven shaft | 28. Speed sensor rotor             |



**Service Information AW30-80LE**




**Transfer position switch**  
 Remove transfer position switch  
 Remove the shift handle.  
 Remove the switch mounting nut and bolt.  
 Remove the wiring clamp and switch.




**Speed sensor**  
 Disconnect the speed sensor wiring connector.  
 Remove the clamp bolt and speed sensor.


**Chain case oil cooler pipe**  
 Disconnect chain case oil cooler pipes from chain case.




**Oil pan**  
 Remove the eleven bolts.  
**Note:** Do not turn the transmission over as this will contaminate the valve body with foreign materials in the bottom of the pan.




**No. 4 solenoid**  
 Disconnect No. 4 solenoid connector.



**Transfer valve body**  
 Remove transfer valve body  
**Note:** Remove the six bolts.  
 Remove the No. 4 solenoid wire clamp bolt.  
 Pull out the No. 4 solenoid wire from the transfer.


**Companion flange**

Using a hammer and chisel, loosen the staked part of the nut.




Using special tool to hold the flange, remove the nut and washer. Remove the companion flange.


Holding wrench : J-8614-01

**Front companion flange**


Remove the front companion flange in the same way as the rear companion flange.


**Extension housing**


Remove the six bolts and remove the extension housing.


**Speedometer drive gear**

Remove speedometer drive gear.


**Transfer chain case cover**

Remove the twelve bolts from the transfer chain case cover.




**Snap ring**

Remove the snap ring.


**Sprocket and driven shaft**

Pull out the chain with the sprocket and driven shaft.




**Front output shaft**

Remove the front output shaft.



**Snap ring**

Remove the snap ring from transfer drive clutch (C-4).




**Transfer drive clutch (C-4)**

Grasp and pull out the front drive clutch.

**Snap ring**

Remove the snap ring from the output shaft.




**Snap ring**


Remove the snap ring from the transfer case.



**Service Information AW30-80LE**




Remove the B-4 inner flange from the case.



**Sun gear**

Pull out the sun gear. Watch for race on rear side of the sun gear.


Watch for bearing on rear side of the sun gear.



**Snap ring and bearing**


Watch for bearing and race on the direct clutch.

Remove the snap ring from transfer case.



**Transfer direct clutch**


Lift the transfer direct clutch from the transfer. Watch for bearing on the front support.



**Speed sensor rotor**

Remove the rear snap ring and remove the sensor rotor and key.

Remove the front snap ring.




**Transfer center support**

**Transfer low speed brake (B-4)**


Grasp the center support and pull out the transfer center support with transfer low speed brake assembly. Watch for race on the planetary gear.

## DISASSEMBLY OF MAJOR COMPONENTS (3)




### Disassembly steps


1. Converter housing
2. Oil pan
3. Oil strainer
4. Oil strainer case
5. Oil tube
6. Solenoid wiring
7. Valve body
8. Check ball, spring and pin
9. Accumulator piston (B-2)
10. Accumulator piston (C-2)
11. Accumulator piston (B-0)
12. Accumulator piston (C-0)
13. Throttle cable
14. Second brake drum gasket




**Converter housing**  
 Remove the six bolts.  
 Remove the transmission housing.




**Oil strainer**  
 Remove eleven bolts holding the lower oil strainer to the upper oil strainer.  
 Remove the lower oil strainer and gasket.



**Oil tube**  
 Pry up both tube ends with a large screwdriver and remove the three tubes.



**Solenoid wiring**  
 Disconnect the connectors from the No. 1, No. 2 and No. 3 solenoids.




Turn over transmission, remove the solenoid wiring stopper plate from the case.  
 Pull the wiring out of the transmission case.






**Service Information AW30-80LE**



**Valve body**


Remove the sixteen bolts from valve body.



Disconnect the throttle cable from the cam.

Remove the valve body from transmission case.


11a-



**Accumulator piston (B-2)**


**Accumulator piston (C-2)**

Remove accumulator pistons and springs from transmission case.



**Accumulator piston (C-0)**

Remove the C-0 accumulator piston.




**Throttle cable**

Turn over transmission and remove throttle cable from transmission case.



## DISASSEMBLY OF MAJOR COMPONENTS (4)




### Disassembly steps

- |   |   |
|---|---|
| 1. Oil pump                               | 15. E-ring and pin  |
| 2. Race                                   | 16. Second coast brake band                                 |
| 3. OD planetary gear and OD direct clutch | 17. Front planetary ring gear                               |
| 4. Race                                   | 18. Bearing and race  |
| 5. OD planetary ring gear                 | 19. Race  |
| 6. Snap ring                              | 20. Snap ring   |
| 7. Flange, plate and disc                 | 21. Front planetary gear                                    |
| 8. Bearing and race                       | 22. Drum and one-way clutch                                 |
| 9. Snap ring                              | 23. Snap ring   |
| 10. OD support                            | 24. Flange, plate and disc                                  |
| 11. Race                                  | 25. Snap ring   |
| 12. Snap ring                             | 26. Rear planetary gear, second brake drum and output shaft |
| 13. Second coast brake piston assembly    | 27. Bearing   |
| 14. Direct clutch and forward clutch      |   |



**Service Information AW30-80LE**

**Important operations**




**Oil pump**

Remove seven bolts fixing the oil pump to the transmission case.


Then using special tool, remove the oil pump.

Puller : J-37230




**OD planetary gear and OD direct clutch**

Remove the overdrive planetary gear and overdrive direct clutch with thrust needle bearing from the transmission case.



**OD planetary ring gear**


Remove the overdrive planetary ring gear from the transmission case.




Measure the stroke applying and releasing the compressed air (4 – 8 kg/cm<sup>2</sup>, 57 – 114 psi or 392 – 785 kPa) as shown in the figure.

Piston stroke	mm(in.)	1.32 – 1.62 (0.0520 – 0.0638)
---------------	---------	----------------------------------

If the values are nonstandard, replace the disc or flange.




Remove the snap ring.



Remove two flanges, two plates and three discs.



## Service Information AW30-80LE




### Snap ring


Using snap ring pliers, remove the snap ring.

### OD support

Remove two bolts fixing the overdrive support assembly to the case.



Install two removed bolts to the OD support, and pull out the OD support assembly.



### Check piston stroke of second coast brake


Place a mark on the second coast brake piston rod as shown in the figure.

Using feeler gauge, measure the stroke applying the compressed air (4 — 8 kg/cm<sup>2</sup>, 57 — 114 psi or 392 — 785 kPa) as shown in the figure.

Piston stroke	mm(in.)	1.5—3.0 (0.059—0.118)
---------------	---------	-----------------------


**Note:** There are two piston rods.

Rod length	71.4 mm (2.811 in.)
	72.9 mm (2.870 in.)



### Snap ring

Using snap ring pliers, remove the snap ring.




### Direct clutch and forward clutch


Remove the direct clutch and forward clutch from the case.




**Service Information AW30-80LE**



**Second coast brake band**  
Remove the second coast brake band from the case.




**Front planetary ring gear**  
Remove the front planetary ring gear from the case.




Using snap ring pliers, remove the snap ring.

**Front planetary gear**  
Remove the front planetary gear from the case.




**Drum and one-way clutch**  
Remove sun gear input drum and one-way clutch



**Check pack clearance of second brake**  
Using a feeler gauge, measure the clearance between the snap ring and flange as shown in the figure.


Clearance	mm(in.)	0.50 – 1.76 (0.0197 – 0.0693)
-----------	---------	----------------------------------

If the values are nonstandard, replace the discs.




**Snap ring**

Using two screwdrivers, remove the snap ring.



**Flange, plate and disc**

Remove the flange, four discs and four plates.




**Check pack clearance of first and reverse brake**

Using a feeler gauge, measure the clearance between the plate and second brake drum as shown in the figure.


Clearance	mm(in.)	0.5 – 1.78 (0.0197 – 0.0701)
-----------	---------	---------------------------------

If the values are nonstandard, replace the discs.



**Snap ring**

Using snap ring pliers, remove the snap ring.




**Rear planetary gear, second brake drum and output shaft**

Remove the rear planetary gear, second brake drum and output shaft as an assembly.




**OIL PUMP**  
**DISASSEMBLY REASSEMBLY**



**Disassembly steps**

1. Oil seal ring
2. O-ring
3. Stator shaft

Oil pump drive gear  
 Oil pump driven gear




**Check tip clearance of both gears**

Measure between the gear teeth and the crescent-shaped part of the pump body.

	mm(in.)
Standard tip clearance	0.11 – 0.14 (0.0043 – 0.0055)
Maximum tip clearance	0.3 (0.012)

If the tip clearance is greater than the maximum, replace the drive gear, driven gear or pump body.




**Check body clearance of driven gear**

Push the driven gear to one side of the body. Use a feeler gauge, measure the clearance.

	mm(in.)
Standard body clearance	0.07 – 0.15 (0.0028 – 0.0059)
Maximum body clearance	0.3 (0.012)

If the body clearance is greater than the maximum, replace the drive gear, driven gear or pump body.



**Check side clearance of both gears**

Using a steel straightedge and a feeler gauge, measure the side clearance of both gears.

	mm(in.)
Standard side clearance	0.02 – 0.05 (0.0008 – 0.0020)
Maximum side clearance	0.1 (0.004)


If the side clearance is greater than the maximum, replace the drive gear, driven gear or pump body.

Using special tool, install a new oil seal.

The oil seal end should be flush with the outer edge of the pump body.

Oil seal installer : J-9617


Coat the oil seal lip with multi purpose grease.



**Stator shaft**

Align the stator shaft with the bolt holes. Tighten the thirteen bolts.

Torque	kg·m(ft.lbs.)	1.1 (7)
--------	---------------	---------




**Oil seal ring**

Coat the oil seal rings with ATF.

Contract the oil seal rings as shown, and install them onto the stator shaft.


**Note:** Do not spread the ring ends too much.



**O-ring**

Coat a new O-ring with ATF and install it to the oil pump body.

		mm(in.)
O-ring size (Reference)	Inside diameter	204.9 (8.067)
	Thickness	3.5 (0.138)








**Service Information AW30-80LE**

**OD PLANETARY GEAR AND OD DIRECT CLUTCH ASSEMBLY (C-O)**


**DISASSEMBLY**

**REASSEMBLY**



**Disassembly steps**

- |  |                       |
|--|-----------------------|
| 1. OD direct clutch assembly           | 9. Thrust bearing     |
| 2. Thrust bearing                      | 10. Snap ring         |
| 3. Snap ring                           | 11. Ring gear flange  |
| 4. Flange, disc and plate              | 12. Race              |
| 5. Snap ring                           | 13. Snap ring         |
| 6. Piston return spring                | 14. Retaining plate   |
| 7. OD direct clutch piston with O-ring | 15. OD one way clutch |
| 8. O-ring                              | 16. Thrust washer     |




**Important operations**

**Check operation of one-way clutch**

Hold the OD direct clutch drum and turn the input shaft.  
The input shaft should turn freely clockwise and should lock counterclockwise.

- ① : Free
- ② : Lock




**OD direct clutch assembly**

Remove OD direct clutch assembly from OD planetary gear.

**Thrust bearing**

Then remove thrust bearing with the race from OD direct clutch drum.




**Snap ring**

Remove snap ring from clutch drum.

**Flange, disc and plate**

Remove flange, disc and plate



**OD direct clutch piston**

Place the oil pump onto the torque converter and then place the OD direct clutch onto the oil pump.

Holding the OD direct clutch piston by hand, apply compressed air to the oil pump to remove the OD direct clutch piston.


Remove the OD direct clutch piston.

**O-ring**

Remove two O-rings from piston.


**Remove retaining plate**


Remove retaining plate from OD planetary gear.



**OD one-way clutch**


Remove OD one-way clutch with outer race.






**Thrust washer**

Install the thrust washer to the OD planetary gear, facing the grooved side upward.




**OD one-way clutch**

Install the one-way clutch into the outer race, with the flanged side of the one-way clutch facing upward.




Install OD one-way clutch with outer race to over-drive planetary gear.



**Retaining plate**

**Snap ring**

Install retaining plate, then install snap ring, using a screwdriver.




**O-ring**


Coat new O-rings with ATF and install them on the OD direct clutch piston.

**OD direct clutch piston with O-ring**

Being careful not to damage the O-rings, press in the OD direct clutch piston into the clutch drum, using both hands.




**Piston return spring**  
Install piston return spring.



**Snap ring**  
Place special tool on the spring retainer, and compress the return spring.


Spring compressor : J-37234

Install the snap ring with snap ring pliers. Be sure the end gap of the snap ring is not aligned with the spring retainer claw.




**Flange, disc and plate**

Install plate and disc, then install the flange, with the flat side facing downward.



**Snap ring**

Install snap ring.




**OD direct clutch assembly**

Align the flukes of discs in the direct clutch.  
Install the OD direct clutch assembly onto the OD planetary gear.

OD SUPPORT ASSEMBLY


DISASSEMBLY

REASSEMBLY




Disassembly steps

- 1. Thrust bearing
- 2. Race
- 3. Thrust washer
- 4. Snap ring
- 5. Piston return spring
- 6. OD brake piston
- 7. O-ring



Check OD brake piston.

Place the OD support assembly onto the direct clutch assembly.




**Oil seal ring**

Coat the two oil seal rings with ATF.

Contract the oil seals as shown, and install them onto the OD support.

**Note:** Do not spread the ring ends more than necessary.



**O-ring**


Coat two new O-rings with ATF and install them on the OD brake piston.

**OD brake piston**

Being careful not to damage the O-rings, press in the brake piston into the OD support, using both hands.

**Piston return spring**


Install piston return spring.



**Thrust washer (plastic)**

Coat the thrust washer with petroleum jelly and install it onto the OD support.

**Note:** Make sure that the lug fits into the hole on the OD support.




**Thrust bearing**

Turn over OD support.

Coat the two races with petroleum jelly, and install them onto the OD support.

**Note:** Race and bearing diameter (Reference)

	mm(in.)	
	Inside	Outside
Race (A)	30.7 (1.209)	47.8 (1.882)
Bearing	32.7 (1.287)	47.7 (1.878)
Race (B)	34.3 (1.350)	47.8 (1.882)



**Race**

Coat the race with petroleum jelly, and install it onto the OD support.

**Note:** Race diameter (Reference)

	mm(in.)
Inside diameter	36.2 (1.425)
Outside diameter	50.9 (2.004)




**Service Information AW30-80LE**

**DIRECT CLUTCH ASSEMBLY (C-2)**

**DISASSEMBLY**


**REASSEMBLY**



**Disassembly steps**

- Clutch drum thrust washer
- Snap ring
- Flange
- Plate and disc

- 5. Snap ring
- 6. Piston return spring
- 7. Direct clutch piston
- 8. O-ring




**Remove direct clutch drum assembly from forward clutch assembly.**



## Service Information AW30-80LE

### Reassembly steps




#### O-ring

Coat new O-rings with ATF and install them on the direct clutch piston.

#### Direct clutch piston

Install direct clutch piston to direct clutch drum.

Being careful not to damage the O-rings, press in the direct clutch piston into the clutch drum, using both hands.




#### Piston return spring

Install piston return spring.

Compress piston return spring and install snap ring in groove.

Place special tool on the spring retainer, and compress the return spring.

Install the snap ring with snap ring pliers. Be sure the end gap of the snap ring is not aligned with the spring retainer claw.




#### Disc and plate

Install plates and discs.


Install in order: P — D — P — D — P — D

P : Plate, D : Disc



#### Flange

Install the flange, with the flat side facing downward.




#### Snap ring

Install the snap ring with a screwdriver. Be sure the end gap of the snap ring is not aligned with the cutout portion of the direct clutch drum.






**Service Information AW30-80LE**



**Check piston stroke of direct clutch (C-2)**

Place the direct clutch assembly onto the OD support assembly.




Using a dial indicator, measure the direct clutch piston stroke by applying and releasing compressed air (4 – 8 kg/cm<sup>2</sup>, 57 – 114 psi or 392 – 785 kPa) as shown.

Piston stroke	mm(in.)	1.03 – 1.33 (0.0406 – 0.0524)
---------------	---------	----------------------------------

If the piston stroke is not within specification, replace the discs and recheck the piston stroke.  
If the piston stroke is non standard, select another flange.

**Note:** There are eight flanges. mm(in.)


No.	Flange thickness	No.	Flange thickness
7	3.0 (0.118)	3	3.4 (0.134)
6	3.1 (0.122)	2	3.5 (0.138)
5	3.2 (0.126)	1	3.6 (0.142)
4	3.3 (0.130)		



**Clutch drum thrust washer (plastic)**

Coat the thrust washer with petroleum jelly and install it onto the direct clutch.

**Note:** Make sure that the lugs fit into the cutout portions on the direct clutch.



**Install direct clutch assembly**

Align the flukes of discs in the direct clutch.

Install the direct clutch assembly onto the forward clutch assembly.

Check that the distance from the direct clutch end to the forward clutch end is 71.2 mm (2.803 in.).




Service Information AW30-80LE

FORWARD CLUTCH ASSEMBLY (C-1)


DISASSEMBLY

REASSEMBLY



Disassembly steps

- |                   |                         |
|-------------------|-------------------------|
| 1. Thrust bearing | 7. Piston return spring |
| 2. Race           | 8. Piston               |
| 3. Snap ring      | 9. O-ring               |
| 4. Flange         | 10. O-ring              |
| 5. Disc and plate | 11. Oil seal ring       |
| 6. Snap ring      | 12. Thrust bearing      |




Check forward clutch drum bushing

Using a dial indicator, measure the inside diameter of the forward clutch drum bushing.

	mm(in.)
Maximum inside diameter	24.08 (0.948)

If the inside diameter is greater than the maximum, replace the forward clutch drum.




**Reassembly steps**

**Thrust bearing**

Coat the assembled bearing and race with petroleum jelly and install it onto the forward clutch drum, with the race side facing downward.

**Note:** Assembled bearing and race (Reference) mm(in.)


Inside diameter	33.6 (1.323)
Outside diameter	47.8 (1.882)



**Oil seal ring**

Coat the three oil rings with ATF. Contract the oil seal rings as shown, and install three oil seal rings onto the forward clutch drum.

**Note:** Do not spread the ring ends more than necessary.




**O-ring**

Coat a new O-ring with ATF and install O-ring on the forward clutch drum.

**O-ring**

Coat new O-rings with ATF and install two O-rings on the forward clutch piston.




**Forward clutch piston**


Being careful not to damage the O-rings, press the forward clutch piston into the forward clutch drum.



**Service Information AW30-80LE**




**Piston return spring**  
Install piston return spring.




**Snap ring**  
Place special tool on the spring retainer, and compress the return spring.

Spring compressor : J-37234  
Install the snap ring with snap ring pliers. Be sure the end gap of the snap ring is not aligned with the spring retainer claw.




**Cushion plate**  
Install cushion plate rounded side down as shown.




**Disc and plate**  
Install discs, plates and flange.  
Install in order : P—D—P—D—P—D—P—D

**Flange**  
And then install the flange, with the rounded edge facing downward.



**Snap ring**  
Install the snap ring with a screw driver. Be sure the end gap of the snap ring is not aligned with the cutout portion of the forward clutch drum.

ALL-TRANS.BY



**Check piston stroke of forward clutch (C-1)**

Using a dial indicator, measure the forward clutch piston stroke by applying and releasing the compressed air (4 — 8 kg/cm<sup>2</sup>, 57 — 114 psi or 392 — 785 kPa) as shown.


	mm(in.)
Piston stroke	3.103 — 3.897 (0.1222 — 0.1534)

If the piston stroke is not within specification, replace the discs, and recheck the piston stroke.

**Race**


**Thrust bearing**

Coat the race and bearing with petroleum jelly, and install them onto the forward clutch drum.




**Note: Race and bearing diameter (Reference) mm(in.)**

	Inside	Outside
Race	26.0 (1.024)	48.9 (1.925)
Bearing	26.0 (1.024)	46.7 (1.839)



**Install direct clutch assembly to forward clutch assembly**

Align the flukes of discs in the direct clutch. Install the direct clutch assembly onto the forward clutch assembly.




Check that distance from the direct clutch end to the forward clutch end is 71.2 mm (2.803 in.).

	mm(in.)
h	71.2 (2.803)

FRONT PLANETARY GEAR


DISASSEMBLY



REASSEMBLY

- 1. Race
- 2. Thrust bearing
- 3. Race
- 4. Front planetary gear

- 5. Race (Metal)
- 6. Thrust bearing
- 7. Race




Thrust bearing and race

Coat the races and bearing with petroleum jelly. Install the race and bearing to the rear side of the planetary gear.

mm(in.)

	Inside	Outside
Bearing	35.5 (1.398)	47.7 (1.878)
Race	33.7 (1.327)	47.6 (1.874)




Race (Metal)

Turn over the planetary gear and install the race. Make sure that the lugs fit into the holes on the planetary gear.

Note: Bearing and races diameter. (Reference)

mm(in.)

	Inside	Outside
Race	34.3 (1.350)	47.8 (1.882)



Thrust bearing and race

Coat the races and bearing with petroleum jelly. Install the race and bearing onto the rear side of the planetary ring gear.


mm(in.)

	Inside	Outside
Race	30.5 (1.201)	53.6 (2.110)
Bearing	32.6 (1.283)	47.7 (1.878)

## PLANETARY SUN GEAR AND NO.1 ONE-WAY CLUTCH


### DISASSEMBLY

### REASSEMBLY



#### Disassembly steps

- |  |                          |
|--|--------------------------|
| 1. One-way clutch and second brake hub | 3. Oil seal ring (Metal) |
| 2. Thrust washer (plastic)             | 4. Snap ring             |
|  | 5. Snap ring             |



#### Check operation of No.1 one-way clutch

Hold the planetary sun gear and turn the second brake hub. The second brake hub should turn freely clockwise and should lock counterwise.

- ① : Free  
② : Lock




**Service Information AW30-80LE**

**Reassembly steps**


**Snap ring**

Install snap ring to planetary sun gear.



**Snap ring**


Install snap ring with snap ring pliers.



**Oil seal ring (Metal)**

Coat the two oil seal rings with ATF.  
Install the two oil seal rings onto the planetary sun gear.


**Note:** Do not spread the ring ends too much.



**Thrust washer (Plastic)**


Install thrust washer.

**Note:** Make sure that the lugs fit into the holes on the sun gear input drum.



**One-way clutch and second brake hub**

Install assembled No.1 one-way clutch and second brake hub onto planetary sun gear as shown.






**SECOND BRAKE ASSEMBLY (B-2)**


**DISASSEMBLY**

**REASSEMBLY**



**Disassembly steps**

- |                            |                         |
|----------------------------|-------------------------|
| 1. Second brake assembly   | 5. Piston return spring |
| 2. Thrust washer (Plastic) | 6. Piston sleeve        |
| 3. Snap ring               | 7. Second brake piston  |
| 4. Spring retainer         | 8. O-ring               |




**Second brake assembly**

Remove second brake assembly from output shaft.



### Reassembly steps



#### O-ring


Coat new O-rings with ATF and install them on the second brake piston.

#### Second brake piston

Being careful not to damage the O-rings, press in the second brake piston into the second brake drum.

#### Piston sleeve

Install piston sleeve.




#### Piston return spring

Install piston return spring.

#### Spring retainer

Install spring retainer.




#### Snap ring

Place special tool on the spring retainer, and compress the return spring.

Spring compressor : J-25048


Install the snap ring with snap ring pliers. Be sure the end gap of the snap ring is not aligned with the spring retainer claw.



#### Thrust washer (plastic)

Coat the thrust washer with petroleum jelly and install it to the second brake piston, with the grooved side facing upward.

**Note:** Make sure that the cutout portions of the thrust washer match the teeth of the spring retainer.




#### Second brake assembly

Install second brake assembly to output shaft.

## REAR PLANETARY GEAR ASSEMBLY AND OUTPUT SHAFT


### DISASSEMBLY

### REASSEMBLY



#### Disassembly steps

1. Second brake assembly
2. Output shaft
3. Oil seal ring
4. Disc, plate and flange
5. Rear planetary gear assembly
6. One-way clutch inner race
7. Snap ring
8. One-way clutch
9. Thrust washer (Plastic)
10. Thrust washer (Plastic)
11. Thrust bearing and race
12. Snap ring
13. Ring gear flange




#### Reassembly steps

1. **Ring gear flange**  
Install ring gear flange to the ring gear.
2. **Snap ring**  
Install snap ring to the ring gear.



**Service Information AW30-80LE**




**Thrust bearing and race**

Coat the races and bearing with petroleum jelly, and install them onto the rear planetary ring gear.

**Note:** Races and bearing diameter (Reference) mm(in.)

	Inside	Outside
Race (A)	28.8 (1.134)	44.8 (1.764)
Bearing	30.1 (1.185)	44.7 (1.760)
Race (B)	27.6 (1.087)	44.8 (1.764)




**Thrust washer (Plastic)**

**Thrust washer (Plastic)**


Coat the thrust washers with petroleum jelly. Install the thrust washers onto both sides of the rear planetary gear, facing the grooved side upward.

**Note:** Make sure that the lugs fit into the cutout portions on the rear planetary gear.



**One-way clutch**


Install the one-way clutch with the flanged side facing upward onto the rear planetary gear.



**Check operation of one-way clutch**

Hold the planetary gear and turn the one-way clutch inner race. The one-way clutch inner race should turn freely counterclockwise and should lock clockwise.


- ① : Lock
- ② : Free



**Disc, plate, flange and cushion plate**


Install a clutch plate onto the rear planetary gear assembly.

**Note:** The claw interval of the plate should be as shown in the figure when viewing the clutch plate from the arrow direction.




Install a cushion plate onto the rear planetary gear assembly

**Note:** The cushion plate should be oriented as shown in the figure.



Install a brake flange onto the rear planetary gear assembly.


Install five clutch discs and five brake plates alternately, starting with clutch disc, onto the rear planetary gear assembly.



**Oil seal ring**

Coat the oil seal ring with ATF and install it to the output shaft.

**Note:** Do not spread the ring ends too much.



**Second brake assembly**


Install second brake assembly to output shaft.




## FIRST AND REVERSE BRAKE (B-3)

## DISASSEMBLY


## REASSEMBLY

**Disassembly steps**

- |                                       |                                       |
|---------------------------------------|---------------------------------------|
| 1. Thrust bearing and race            | 6. Reaction sleeve                    |
| 2. Snap ring                          | 7. O-ring                             |
| 3. Piston return spring               | 8. 1st and reverse brake piston No. 1 |
| 4. 1st and reverse brake piston No. 2 | 9. O-ring                             |
| 5. O-ring                             |                                       |

**Reassembly steps**

1. **O-ring**  
Coat three new O-rings with ATF.  
Install the two O-rings on the No. 1 piston.
2. **O-ring**  
Install the O-ring on the reaction sleeve.
3. **1st and reverse brake piston No. 1**  
Install the No. 1 piston to the reaction sleeve.




**O-ring**

Coat a new O-ring with ATF and install it on the No. 2 piston.

**Reaction sleeve**


Install the No. 1 piston with reaction sleeve onto the No. 2 piston.



**1st and reverse brake piston No. 2**


Align the teeth of the No. 2 piston into the proper grooves.

Being careful not to damage the O-rings, press in the No. 2 with No. 1 first and reverse brake pistons into the transmission case.




**Return spring**

Place piston return spring onto No. 2 piston.



**Check first and reverse brake piston**

Make sure the first and reverse brake piston moves smoothly when applying and releasing the compressed air into the transmission case.



**Thrust bearing and race**

Coat the assembled bearing and race with petroleum jelly.

Install the assembled bearing and race facing the bearing side upward.



**Note:** Assembled bearing and race diameter. (Reference) mm(in.)

Inside diameter	39.2 (1.543)
Outside diameter	57.7 (2.272)




Service Information AW30-80LE

TRANSMISSION VALVE BODY ASSEMBLY



**No. 1 gasket (Upper valve body side)**

Position new No. 1 gasket ① on upper valve body. Align a new No. 1 gasket at each bolt hole.




**Valve body plate**

Position valve body plate ② on No. 1 gasket. Align the plate at each bolt hole.

**No. 2 gasket (Lower valve body side)**

Position new No. 2 gasket 2 on plate. Align a new No. 2 gasket at each bolt hole.






Confirm clip and four retainers are installed correctly

**Retainer**

Place a mark on the bevel when the retainer is positioned.


**Note:** When reassembling, position the retainer in the same position.



**INSPECTION AND REPAIR**

**Inspect strainer**

Inspect strainer for residual adhesive and damage, and clean and replace as necessary.




**Inspect valve springs**

Check for damage, squareness, rust and distorted coils.


Measure the spring free height and replace if less than shown below.

	mm(in.)
	Spring Free length
(1) Check valve	20.2 (0.795)
(2) Pressure relief valve	11.2 (0.441)
(3) 1-2 shift valve	30.8 (1.213)
(4) Primary regulator valve	66.7 (2.626)
(5) Accumulator control valve	35.7 (1.406)






**Service Information AW30-80LE**




**No. 3 solenoid**  
 Install a new O-ring to the solenoid.  
 Install the solenoid to the valve body.

Torque	kg·m(ft.lbs.)	1.00 (7.23)
--------	---------------	-------------




**No. 1 solenoid**  
**No. 2 solenoid**  
 Install a new O-ring to the solenoid.  
 Install the solenoid to the valve body.

Torque	kg·m(ft.lbs.)	1.0 (7.23)
--------	---------------	------------



**Strainer**  
 Install the three strainers to the valve body as shown.



Strainer	Height	Diameter
(A) Solenoid oil strainer	11.0 (0.433)	10.3 (0.406)
(B) Throttle oil strainer	19.5 (0.768)	10.3 (0.406)



**Check valve and spring**  
**Pressure relief valve**  
 Install check valve, pressure relief valve and springs.


LOWER VALVE BODY  
REASSEMBLY


ALL-TRANS.BY



- |                          |  |
|--------------------------|--|
| 1. Check valve           | 11. Plug, spring and 1-2 shift valve                 |
| 2. Pressure relief valve | 12. Retainer   |
| 3. Strainer              | 13. Sleeve with plunger, spring and washer           |
| 4. No. 1 solenoid        | 14. Primary regulator valve                          |
| 5. No. 2 solenoid        | 15. Clip   |
| 6. No. 3 solenoid        | 16. Pressure regulator plug                          |
| 7. Retainer              | 17. Retainer   |
| 8. Plug                  | 18. Sleeve with accumulator control valve and spring |
| 9. Release control valve |  |
| 10. Retainer             |  |

UPPER VALVE BODY







- |   |                                  |
|---|----------------------------------|
| 1. Low-coast modulator valve                            | 21. Retainer                     |
| 2. Spring   | 22. Spring                       |
| 3. Plug   | 23. Second coast modulator valve |
| 4. Retainer   | 24. Plug                         |
| 5. 2 - 3 shift valve                                    | 25. Retainer                     |
| 6. Spring   | 26. Spring                       |
| 7. Plug   | 27. 3 - 4 shift valve            |
| 8. Retainer   | 28. Plug                         |
| 9. Spring   | 29. Retainer                     |
| 10. Cut-back valve                                      | 30. Throttle valve               |
| 11. Plug  | 31. Valve stopper                |
| 12. Retainer  | 32. Adjusting ring               |
| 13. Spring  | 33. Spring                       |
| 14. Secondary regulator valve                           | 34. Spring                       |
| 15. Plug  | 35. Down-shift plug              |
| 16. Retainer  | 36. Pin                          |
| 17. Plunger   | 37. Sleeve                       |
| 18. Spring  | 38. Spring                       |
| 19. Lock-up relay valve                                 | 39. Throttle cam assembly        |
| 20. Sleeve with plunger, spring and lock-up relay valve | 40. Check ball                   |
|   | 41. Strainer                     |




**Service Information AW30-80LE**




**Valve stopper**  
Install the valve stopper as shown.



**Adjusting ring**  
Turn over valve body, and install the same number of adjusting rings as were removed during disassembly.




**Make sure pin, seven retainers and valve stopper are installed correctly**




**Check ball**  
Install the three types of check balls to the valve body.

Check ball	Diameter mm(in.)
(A) Rubber ball	6.35 (0.2500)
(B) Steel ball	5.56 (0.2189)
(C) Steel ball	7.14 (0.2811)




**Strainer**  
Install strainer.



**Reassembly steps**

- 1. Oil seal
- 2. Oil seal
- 3. Spacer
- 4. Manual valve lever
- 5. Manual valve lever shaft
- 6. Pin




**Spacer**

**Manual valve lever**

Assemble a new spacer to the manual valve lever.


**Manual valve lever shaft**

Install the manual valve lever shaft to the transmission case through the manual valve lever by the threads.



**Pin**

Drive in the pin with the slot at a right angle to the shaft.





Match the spacer hole to the lever staking hollow and stake the spacer to the lever. Make sure the manual valve lever shaft turns smoothly.



**Service Information AW30-80LE**

**TRANSFER DIRECT CLUTCH ASSEMBLY (C-3)**




**Snap ring**

Place special tool on the spring retainer, and compress the springs.

Spring compressor : J-37234

Install the snap ring with a snap ring pliers. Be sure the end gap of snap ring is not aligned with the spring retainer claw.




**Plate, disc and flange**

Install plates, discs and flange.

Install in order :

Thin plate - Disc - Thick plate - Disc - Thick plate - Disc - Thick plate - Disc - Thick plate - Disc - Thin plate - Disc

Then install the flange, with the flat side facing downward.



**Snap ring**

Install outer snap ring.

Check that the end gap of the snap ring is not aligned with one of the cutouts.


**Note:** There are four flange sizes

		mm(in.)
3.9 (0.154)		4.3 (0.169)
4.1 (0.161)		4.5 (0.177)




**TRANSFER LOW SPEED BRAKE (B-4)  
AND CENTER SUPPORT**

ALL-TRANS.BY



**Reassembly steps**

- |                                    |   |
|------------------------------------|---|
| 1. Oil seal ring                   | 8. Thrust bearing and race                |
| 2. O-ring                          | 9. Planetary ring gear                    |
| 3. O-ring                          | 10. Disc, plate, flange and cushion plate |
| 4. Transfer low speed brake piston | 11. Return spring                         |
| 5. Ring gear flange                | 12. Race                                  |
| 6. Snap ring                       | 13. Thrust bearing                        |
| 7. Race                            | 14. Transfer center support               |




**Oil seal ring**

Spread the ring apart and install it into the groove to the center support. Push the one end of the ring into the groove and hook both ends by hand.

Oil seal ring (Reference)	mm(in)
Inside diameter	51.6 (2.0315)



**Service Information AW30-80LE**



**O-ring**


Install new O-rings to the piston.

**O-ring**

Install new O-ring to the center support.

**Transfer low speed brake piston**

Push in the center support and piston.




**Ring gear flange**

**Snap ring**

Install the flange into the ring gear and install the snap ring.


Snap ring (Reference)		mm(in.)
Inside diameter		129.4 (5.0945)



**Race**

Coat the race with petroleum jelly, and install it into the planetary gear front side.


Bearing race (Reference)		mm(in.)
Inside diameter	Outside diameter	
23.1 (0.9094)	45.0 (1.7717)	



**Thrust bearing and race**


Install the bearing and race onto the planetary gear rear side.

Bearing and race (Reference)			mm(in.)
	Inside diameter	Outside diameter	
Bearing	35.0 (1.3780)	54.36 (2.1402)	
Race	36.3 (1.4291)	53.9 (2.1220)	



**Planetary ring gear**

Install planetary ring gear to output shaft.




**Disc, plate, flange and cushion plate**

Install discs, plates, outer flange and cushion plate.

Install in order :


Disc - Plate - Disc - Plate - Plate - Disc - Plate - Disc -  
Disc - Plate - Disc - Flange - Cushion plate

**Note:** Install the inner flange when assembling the transfer case.



**Return spring**

Install return spring.




**Race**

Coat the race with petroleum jelly.

Install the race to the planetary ring gear.

(Reference)	mm(in.)	
	Inside diameter	Outside diameter
Race	36.3 (1.4291)	53.9 (2.1220)




**Thrust bearing**

Coat the bearing with petroleum jelly.

Install the bearing to the center support.

(Reference)	mm(in.)	
	Inside diameter	Outside diameter
Bearing with race	38.0 (1.4961)	57.3 (2.2559)




**Transfer center support**

Install the center support to the output shaft.



**TRANSFER FRONT DIRECT CLUTCH ASSEMBLY (C-4)**



**Reassembly steps**


- 1. O-ring
- 2. Piston
- 3. Return spring
- 4. Snap ring
- 5. Plate, disc and flange
- 6. Snap ring

**O-ring**

Install new O-ring on the piston. Coat the O-ring with ATF.

(Reference) mm(in)

Inside diameter	Inner	Outer
	60.1 (2.3661)	134.5 (5.2953)



**Piston**


Being careful not to damage the O-ring, press the piston into the drum.

**Return spring**

Install piston return spring and snap ring in place.



**Service Information AW30-80LE**




**Snap ring**

Place special tool on the return spring, and compress the springs.

Spring compressor : J-37234

Install the snap ring with snap ring pliers. Be sure the end gap of snap ring is not aligned with the spring seat claw.




**Plate, disc and flange**

Install plates, discs and flange

Install in order :

Plate - Disc - Plate - Disc - Plate - Disc - Plate - Disc - Plate - Disc - Plate - Disc


Then install the flange, with the flat side facing downward.



**Snap ring**

Install outer snap ring.

Check that the end gap of the snap ring is not aligned with one of cutouts.



**Recheck piston stroke of front drive clutch**


Install the front drive clutch onto the transfer center support.

Using a dial indicator, measure the piston stroke while applying and releasing the compressed air (4–8 kg/cm<sup>2</sup>, 57–114 psi or 392–784 kPa) as shown.

	mm(in.)
Standard piston stroke	2.38 – 3.22 (0.0937 – 0.1268)

If the piston stroke exceeds the limit, replace the discs and recheck the piston stroke.  
If the piston stroke is less than the limit, parts may be misassembled. If so, reinstall them.

## TRANSFER CASE AND FRONT SUPPORT



### Reassembly steps

- |                            |                       |
|----------------------------|-----------------------|
| 1. Oil seal ring           | 7. Spacer             |
| 2. Oil seal                | 8. Manual valve lever |
| 3. Parking lock pawl       | 9. Manual valve shaft |
| 4. Parking lock pawl shaft | 10. Pin               |
| 5. Spring                  | 11. Apply gasket      |
| 6. E-ring                  | 12. Apply gasket      |

### Important operations

#### Oil seal ring



Install two oil seal rings to front support.

**Note:** Do not spread the ring ends more than necessary.

Size of oil seal ring (Reference)		mm(in.)
Inside diameter		51.6 (2.031)

#### Oil seal


Using a screwdriver, remove the oil seal from the case.



**Oil seal**

Using special tool and a hammer, drive in the new oil seal to the case.

Oil seal installer : J-37232-2



**Parking lock pawl**

**Parking lock pawl shaft**

**Spring**

Install parking lock pawl, parking lock pawl shaft and spring in case.


**E-ring**

Install E-ring to the parking lock pawl shaft.

**Spacer**

Assemble the new spacer to the manual level.

**Note:** Always replace the spacer and roll pin with a new one. Never reuse a pin after it has been removed.



**Manual valve lever**

**Manual valve shaft**

Install the manual valve lever shaft to the transfer case through the manual valve lever.


**Pin**

Drive in a new roll pin with the slot at a right angle to the shaft.

Match the spacer hole to the lever staking hollow and stake the spacer to the lever.


**Apply gasket**


Install the apply gasket to the transfer case inner side.



**Apply gasket**


Install the two apply gaskets to the transfer case front side.






**Reassembly steps**

- |                              |                       |
|------------------------------|-----------------------|
| 1. Oil seal                  | 7. O-ring             |
| 2. Front drive shaft bearing | 8. Spring             |
| 3. Snap ring                 | 9. Accumulator piston |
| 4. Rear drive shaft bearing  | 10. Cover             |
| 5. Snap ring                 | 11. Reserve cover     |
| 6. Oil seal                  | 12. Apply gasket      |




**Oil seal**  
 Using a special tool and a hammer, drive in the front oil seal.  
 Oil seal installer : J-37239



**Front drive shaft bearing**  
 Install the bearing to the transfer chain case.


**Snap ring**  
 Install the snap ring to the transfer case.





**Rear drive shaft bearing**

Install the front bearing.



**Snap ring**

Install the snap ring.

**O-ring**


Install the new O-rings to the accumulator piston and cover.

Size of O-rings (Reference) mm(in.)

		Diameter	Thickness
Piston	Outer	29.8 (1.1732)	2.6 (0.1024)
	Inner	23.6 (0.9291)	2.6 (0.1024)
Cover		31.7 (1.2480)	2.6 (0.1024)

**Accumulator piston**


Install the spring and accumulator piston.



**Cover**

Install the accumulator piston cover and tighten the three bolts.


Torque	kg-m(ft.lbs.)	0.8 – 1.2 (5.8 – 8.7)



**Reserve cover**



Install reserve cover and tighten the five bolts.

Torque	kg-m(ft.lbs.)	0.8 – 1.2 (5.8 – 8.7)



**Apply gasket**

Install two apply gaskets.




**Front drive shaft bearing**

Using special tool and press, press in the bearing to the transfer chain cover.

Installer : J-37241


Grip : J-8092



**Oil seal**

Using special tool and a hammer, drive in the oil seal to the transfer chain cover.

Oil seal installer : J-37240




**Strainer**

Install the strainer and tighten the four bolts.

Torque	kg-m(ft.lbs.)	0.7 (5.1)
--------	---------------	-----------




**TRANSFER OIL PUMP**



**Reassembly steps**

1. Driven gear
2. Drive gear
3. Check valve and spring
4. Plate
5. Oil pump body




**INSPECTION AND REPAIR**

**Check body clearance of driven gear**

Push the driven gear to one side of the body. Using a feeler gauge, measure the clearance.

	mm(in.)
Standard body clearance	0.3 (0.012)

If the body clearance is greater than the maximum, replace the drive gear, driven gear or pump body.




**Check tip clearance of both gears**

Measure between the gear teeth and the crescent-shaped part of the pump body.

	mm(in.)
Standard tip clearance	0.3 (0.012)

If the tip clearance is greater than the maximum, replace the drive gear, driven gear or pump body.



**Check side clearance of both gears**

Using a steel straightedge and a feeler gauge, measure the side clearance of both gears.


	mm(in.)
Standard side clearance	0.04 – 0.15 (0.0016 – 0.0060)
Maximum side clearance	0.3 (0.012)

If the side clearance is greater than the maximum, replace the drive gear, driven gear or pump body.




**Service Information AW30-80LE**

**Important operations**




**Driven gear**

Coat the driven gear with ATF and install the driven gear to the oil pump body.




**Drive gear**

Coat the drive gear with ATF and install the drive gear to the oil pump body.




**Check valve and spring**

Coat the check valve and spring with ATF and install them to the oil pump body.



**Plate**


Install the plate to the oil pump body.



**Oil pump body**


Install the oil pump body with plate to the oil pump cover and tighten the three bolts.

Torque	kg-m(ft.lbs.)	0.8 — 1.2 (5.8 — 8.7)
--------	---------------	-----------------------




**Reassembly steps**

- |             |                    |
|-------------|--------------------|
| 1. Oil seal | 3. Snap ring       |
| 2. Bearing  | 4. Retaining plate |




**Oil seal  
Retaining plate**


Using a screwdriver, remove the oil seal and retaining plate.




**Oil seal**  
Using a special tool and a hammer, install the oil seal to the extension housing.  
Installer : J-37239

**TRANSFER VALVE BODY**

**Reassembly steps**

- |                      |                     |
|----------------------|---------------------|
| 1. Upper valve body  | 7. Lower valve body |
| 2. Check ball        | 8. Detent spring    |
| 3. Oil strainer      | 9. Manual valve     |
| 4. Plate and gasket  | 10. No. 4 solenoid  |
| 5. Center valve body |                     |
| 6. Plate and gasket  |                     |



**Check ball**
**Oil strainer**

Install the two oil strainers and four check balls to the upper valve body.




**Plate and gasket**

Position new No. 1 gasket ① on upper valve body.  
Align new No. 1 gasket at each bolt hole.




Position new No. 2 gasket ② on plate.  
Align a new No. 2 gasket at each bolt hole.




**Center valve body**

Place center valve body on top of upper rear valve body.



**Plate and gasket**


Position new No. 1 gasket ① on lower valve body.  
Align new No. 1 gasket at each bolt hole.



Position new No. 2 gasket ② on plate.  
Align new No. 2 gasket at each bolt hole.




**Service Information AW30-80LE**




**Lower valve body**

Place lower valve body with plate and gaskets on top of center valve body.



Tighten bolts on both sides.


Torque	kg-m(ft.lbs.)	0.7 (5.1)
--------	---------------	-----------



**Detent spring**


Install detent spring.

Torque	kg-m(ft.lbs.)	0.7 (5.1)
--------	---------------	-----------



**Manual valve**

Insert manual valve.




**No. 4 solenoid**

Torque	kg-m(ft.lbs.)	1.0 (7.23)
--------	---------------	------------




L-TRANS.BY




**Reassembly steps**

- |  |  |
|--|--|
| <ul style="list-style-type: none"> <li>1. Spring</li> <li>2. Accumulator control valve</li> <li>3. Plug</li> <li>4. Retainer</li> <li>5. Spring</li> <li>6. Relay valve</li> <li>7. Relay plunger</li> </ul> | <ul style="list-style-type: none"> <li>8. Plug</li> <li>9. Retainer</li> <li>10. Spring</li> <li>11. Low shift valve</li> <li>12. Inhibitor valve</li> <li>13. Plug</li> <li>14. Retainer</li> </ul> |
|--|--|



**Disassembly steps**

- |                       |                          |
|-----------------------|--------------------------|
| 1. Retainer           | 5. Retainer              |
| 2. Plug               | 6. Plug                  |
| 3. Spring             | 7. Spring                |
| 4. Shift timing valve | 8. Orifice control valve |




**Disassembly steps**

1. Retainer
2. Plug
3. Spring
4. C-3 accumulator valve

**Reassembly steps**

To reassemble, follow the disassembly procedure in reverse order.



**INSPECTION AND REPAIR**

**Inspect accumulator valve spring**


Check for damage, squareness, rust and collapsed coils. Measure the spring free height and replace it if less than the specification.

Free length	mm(in.)	55.7 (2.193)
-------------	---------	--------------




# SERVICE INFORMATION


## TRANSMISSION



## TRANSFER CASE



## REASSEMBLY OF MAJOR COMPONENTS




### Reassembly steps

- |  |  |
|--|--|
| 1. Bearing   | 17. Bearing and race                       |
| 2. Rear planetary gear, second brake drum and output shaft | 18. Direct clutch and forward clutch       |
| 3. Snap ring   | 19. Second coast brake piston assembly     |
| 4. Second brake piston sleeve                              | 20. Snap ring                              |
| 5. One-way clutch  | 21. Race                                   |
| 6. Flange plate and disc                                   | 22. OD support                             |
| 7. Snap ring   | 23. Snap ring                              |
| 8. Drum  | 24. Flange, plate and disc                 |
| 9. Front planetary gear                                    | 25. Snap ring                              |
| 10. Snap ring  | 26. Bearing and race                       |
| 11. Race   | 27. OD planetary ring gear                 |
| 12. Second coast brake band                                | 28. Bearing and race                       |
| 13. E-ring and pin   | 29. Race                                   |
| 14. Bearing and race                                       | 30. OD planetary gear and OD direct clutch |
| 15. Race   | 31. Bearing                                |
| 16. Front planetary ring gear                              | 32. Race                                   |
|  | 33. Oil pump                               |



## Service Information AW30-80LE




### Bearing

Coat the assembled bearing and race with petroleum jelly and install it onto the case.

Assembled bearing and race  
(Reference)


mm(in.)

Bearing and race	Diameter
Inside	39.2 (1.543)
Outside	57.7 (2.272)




### Rear planetary gear, second brake drum and output shaft

Align the teeth of the second brake drum, flanges, discs and plates as shown in the figure.




Align the splines of the transmission case and the assembled rear planetary gear, second brake drum and output shaft, indicated by A in the figure at left.



### Snap ring

Using snap ring pliers, install the snap ring.




**Check pack clearance of first and reverse brake**

Using a thickness gauge, measure the clearance between the plate and second brake drum as shown in the figure.


Clearance	mm(in.)	0.50 – 1.78 (0.0197 – 0.0701)
-----------	---------	----------------------------------

If the values are nonstandard, check for an improper installation.




**Second brake piston sleeve**

Install second brake piston sleeve.



**One-way clutch**

Install one-way clutch




**Flange plate and disc**

Install flange, discs and plates.

Install the 2.5 mm (0.098 in.) thick plate with the rounded edge side of the plate facing the disc.

Alternately install four discs and three plates (Disc first)

Install the flange with the rounded edge of the flange facing the disc.



**Snap ring**

Install the snap ring.



## Service Information AW30-80LE

### Check pack clearance of second brake

Using a thickness gauge, measure the clearance between the snap ring and flange as shown in the figure.


Clearance	mm(in.)	0.50 – 1.76 (0.0197 – 0.0693)

If the values are nonstandard, check for an improper installation.

### Drum

While turning the sun gear input drum clockwise, install it into the one-way clutch.


**Note:** Confirm the thrust washers are installed correctly.




### Front planetary gear and bearing

Install the front planetary gear to the sun gear.

**Note:** Confirm the bearing and race is installed correctly.




With wooden blocks under the output shaft, stand the transmission on the output shaft.



### Snap ring

Using snap ring pliers, install the snap ring.












## Service Information AW30-80LE

ALL-TRANS.BY



### Race

Coat the bearing race with petroleum jelly and install it onto the front planetary gear.

Bearing race diameter (Reference)		mm(in.)
Bearing race	Diameter	
Inside	34.3 (1.350)	
Outside	47.8 (1.882)	

### Second coast brake band

Insert the second coast brake band to the case.

### E-ring and pin

Install the pin through the brake band.

Install the E-ring to the pin.


### Bearing and race

Coat the bearing and race with petroleum jelly and install them onto the forward clutch.

Bearing and race diameter (Reference)		mm(in.)
	Inside	Outside
Bearing	26.0 (1.024)	46.7 (1.839)
Race	26.0 (1.024)	48.9 (1.925)




## Service Information AW30-80LE




### Race

Coat the race with petroleum jelly and install it onto the front planetary ring gear.

Race diameter (Reference)		mm(in.)
	Inside	Outside
Race	26.8 (1.055)	47.0 (1.850)




Align the flukes of the discs in the forward clutch.



### Front planetary ring gear


Align the spline of the front planetary gear with the flukes of the discs and install the front planetary gear to the forward clutch.



### Bearing and race


Coat the bearing and race with petroleum jelly and install them onto the ring gear.

Bearing and race diameter (Reference)		mm(in.)
	Inside	Outside
Bearing	32.6 (1.283)	47.7 (1.878)
Race	30.6 (1.205)	53.6 (2.110)



### Direct clutch and forward clutch


Install the assembled direct clutch, forward clutch and front planetary ring gear into the transmission case.



Using vernier calipers, measure the distance between the sun gear input drum and direct clutch drum as shown in the figure.

Height	mm(in.)	9.8 – 11.8 (0.386 – 0.465)
--------	---------	-------------------------------


If the values are nonstandard, check for an improper installation.



Coat the assembled bearing and race with petroleum jelly and install it onto the forward clutch.

Assembled bearing and race diameter  
(Reference) mm(in.)

	Inside	Outside
Bearing and race	33.6 (1.323)	47.8 (1.882)




**Second coast brake piston assembly**

Coat the oil seal ring with ATF and install it to the second coast brake piston.

Install the washer, spring and piston to the piston rod. Install the E-ring.

- ①: Second coast brake piston
- ②: Oil seal
- ③: Piston rod




**Snap ring**

Coat two new oil seals with ATF and install them to the piston cover.


Install the spring, second coast brake piston assembly and piston cover to the case.

Using snap ring pliers, install the snap ring.



**Check piston stroke of second coast brake**


Place a mark on the second coast brake piston rod as shown in the figure.



Using wire gage, measure the stroke by applying the compressed air (4 – 8 kg/cm<sup>2</sup>, 57 – 114 psi or 392 – 785 kPa) as shown in the figure.

Piston stroke	mm(in.)	1.5 – 3.0 (0.059 – 0.118)
---------------	---------	------------------------------


If the values are nonstandard, check for an improper installation.



**Race**


Coat the race with petroleum jelly and install it onto the overdrive support assembly.

Race diameter (Reference)		mm(in.)
	Inside	Outside
Race	36.2 (1.425)	50.9 (2.004)




**OD support**

Aim the bolt and oil holes of the overdrive support toward the valve hole side, and align them with the bolt hole of the transmission case and insert.




**Snap ring**

Using snap ring pliers, install the snap ring as shown in the figure.



Install and tighten the two bolts.

Torque	kg·m(ft.lbs.)	2.6 (19)
--------	---------------	----------




**Bearing and race**

Coat the bearing and races with petroleum jelly and install them onto the overdrive support.


Bearing and races diameter (Reference) mm(in.)

	Inside	Outside
Bearing	32.6 (1.283)	47.7 (1.878)
Race (Front)	30.7 (1.209)	47.7 (1.878)
Race (Rear)	34.3 (1.350)	47.8 (1.882)



**OD planetary ring gear**

Install the overdrive planetary ring gear.




**Bearing and race**

Coat the bearing and race with petroleum jelly and install them onto the planetary ring gear.

Bearing and race diameter (Reference) mm(in.)

	Inside	Outside
Bearing	26.0 (1.024)	46.7 (1.839)
Race	24.2 (0.953)	47.8 (1.882)




**Race**

Coat the race with petroleum jelly and install it onto the planetary gear.

Race diameter (Reference) mm(in.)

	Inside	Outside
Race	27.2 (1.071)	41.8 (1.646)




**OD planetary gear and OD direct clutch**

Install the overdrive planetary gear and direct clutch.




**Service Information AW30-80LE**



**Bearing**


Coat the assembled bearing and race with petroleum jelly and install it onto the direct clutch.

Bearing and race diameter (Reference)		mm(in.)
	Inside	Outside
Bearing and race	28.9 (1.138)	50.2 (1.976)



Install the (flat ring) 4.0 mm (0.157 in.) thick flange with the rounded edge side of the flange facing the disc.

Alternately install three discs and two plates. (Disc first)




Install the (stepped ring) flange with the flat side of the flange facing the disc.

Install the snap ring.

**Race**

Coat the race with petroleum jelly and install it onto the oil pump.

Race diameter (Reference)		mm(in.)
	Inside	Outside
Race	28.1 (1.106)	47.2 (1.858)



**Oil pump**


Coat the O-ring with ATF and install it around the pump body.

Place the oil pump through the input shaft, and align the bolt holes of the pump body with the transmission case.

Hold the input shaft, and lightly press the oil pump body to slide the oil seal rings on the stator shaft through the direct clutch drum.

**CAUTION:** Do not push on the oil pump strongly or the oil seal ring will stick to the direct clutch drum.


Install the seven bolts.



Torque	kg-m(ft.lb.)	2.2 (16)
--------	--------------	----------




**Service Information AW30-80LE**



**Throttle cable**


Coat a new O-ring with the ATF and install it to the cable.

Install the cable to the case.



**Second brake drum gasket**

Install a new brake drum gasket to the transmission case.




**Individual piston operation inspection**

Check for the sound of operation while injecting compressed air into the oil hole indicated in the figure.

- 1: OD direct clutch
- 2: Direct clutch
- 3: Forward clutch
- 4: OD brake
- 5: Second coast brake
- 6: Second brake
- 7: First and reverse brake






**Note:** When inspecting the direct clutch, check with the C-0 accumulator piston hole closed. If there is no noise, disassemble and check the condition of the parts.

A : C-0 Accumulator piston hole



**Accumulator piston**

Coat the O-ring with ATF and install it to the piston. Install the three springs and four accumulator pistons to the bore as shown in the figure.



Install the two pins and three springs.

mm(in.)

Piston	Outer diameter	Height
B-2	36.9 (1.453)	68.5 (2.697)
C-2	36.9 (1.453)	62.6 (2.465)
B-0	31.9 (1.256)	52.0 (2.047)
C-0	29.9 (1.177)	49.0 (1.929)

Pin	Outer diameter	Height
B-2	12.0 (0.472)	35.2 (1.386)
C-2	13.7 (0.539)	33.2 (1.307)

Spring	Free length	Outer diameter
(1) B-2 (Inner)	53.5 (2.106)	19.7 (0.776)
(2) B-2 (Outer)	46.0 (1.811)	19.4 (0.764)
(3) C-2 (Inner)	48.1 (1.894)	20.3 (0.799)
(4) C-2 (Outer)	44.0 (1.732)	21.0 (0.827)
(5) B-0	66.0 (2.598)	16.5 (0.650)
(6) C-0	67.0 (2.638)	17.8 (0.701)


### Check ball, spring and pin

Install new check ball body and spring

### Valve body


Align the groove of the manual valve to the pin of the lever.





Connect the throttle cable to the cam.


Confirm the springs into the accumulator piston are installed correctly.



Install the sixteen bolts.

**Note:** Each bolt length (mm) is indicated in the figure.


Torque	kg-m(ft.lbs.)	1.0 (7.2)
--------	---------------	-----------




**Solenoid wiring**

Coat a new O-ring with ATF, and install it to the solenoid wiring.

Insert the solenoid wiring to the case and install the stopper plate.



Connect the connectors to the No. 1, No. 2 and No. 3 solenoids.




**Oil tube**

Using a plastic hammer, install the three tubes into the positions shown in the figure.

**CAUTION:** Be careful not to bend or damage the tubes.




**Service Information AW30-80LE**




**Oil strainer case**

Install two new gaskets to the oil strainer.



Install the oil strainer case with the gaskets to the valve body. Tighten the five bolts.


Torque	kg-m(ft.lbs.)	1.0 (7.2)
--------	---------------	-----------



**Oil strainer**

Install the oil strainer with a new gasket to the oil strainer case. Tighten the eleven bolts.

Torque	kg-m(in.lbs.)	0.7 (5.1)
--------	---------------	-----------



**Oil pan**


Install magnet in pan.

**Note:** Make sure that the magnet does not interfere with the oil tubes.

Remove any packing material and be careful not to drop oil on the contacting surfaces of the transmission case and oil pan.

Apply liquid gasket (TB1281 or its equivalent) to the oil pan as shown in the figure.

**Note:** Install the oil pan as soon as the seal packing is applied.




Install and tighten the nineteen bolts.

Torque	kg-m(ft.lbs.)	0.75 (5.4)
--------	---------------	------------




## REASSEMBLY OF MAJOR COMPONENTS



## Reassembly steps


- |                                       |                                 |
|---------------------------------------|---------------------------------|
| 1. Speed sensor rotor                 | 15. Sprocket and driven shaft   |
| 2. Transfer case                      | 16. Snap ring                   |
| 3. Transfer front support             | 17. Transfer chain case cover   |
| 4. Transfer direct clutch             | 18. Speedometer drive gear      |
| 5. Snap ring and bearing              | 19. Extension housing           |
| 6. Sun gear                           | 20. Front companion flange      |
| 7. Transfer low speed brake (B-4)     | 21. Companion flange            |
| 8. Transfer center support            | 22. Parking lock pawl bracket   |
| 9. Snap ring                          | 23. No. 4 solenoid              |
| 10. Snap ring                         | 24. Transfer valve body         |
| 11. Transfer front drive clutch (C-4) | 25. Oil pan                     |
| 12. Snap ring                         | 26. Speed sensor                |
| 13. Front output shaft                | 27. Transfer position switch    |
| 14. Transfer chain case               | 28. Chain case oil cooler pipes |

ALL-TRANS.BY



**Speed sensor rotor**

Install the snap ring to the output shaft.  
 Install the key and sensor rotor to the output shaft.  
 Install the snap ring to the output shaft.




**Transfer case**

Clean contacting surfaces of any residual packing material, using gasoline or alcohol.  
 Install two apply gaskets ② to the transfer case.  
 Apply liquid gasket ① (THREE BOND TB1281 or its equivalent) to the case.

**NOTE:**


**Install the transfer case within 10 minutes after applying liquid gasket.**

Install apply gasket to the transfer case.



Install the case and tighten the seven bolts.


Torque	kg-m(ft.lbs.)	3.5 (25)
--------	---------------	----------




**Transfer front support**


Install front support to transfer case.

Torque	kg-m(ft.lbs.)	3.5 (25)
--------	---------------	----------






**Transfer direct clutch**  
Install the bearing to the front support.



Using the hooks, install the direct clutch to the transfer case.




**Snap ring and bearing**

Install the snap ring.

**Snap ring (Reference)**

Inside diameter	mm(in.)	173 (6.81)
-----------------	---------	------------


Install the bearing and race.



**Sun gear**

Install the sun gear.


Install the bearing to rear side of the sun gear.




Install the bearing race ① to the output shaft.




**Service Information AW30-80LE**




**Install the output shaft to the transfer case.**




**Transfer low speed brake (B-4)**  
**Install the B-4 inner flange to the case.**



**Install six discs and five plates. (Disc first)**  
**Install brake flange.**




**Install cushion plate.**




**Install low speed brake piston return spring.**

Install bearing race to the output shaft.




**Center support**

Install bearing to the center support.



Align the center support hole (A) and transfer case hole (A).

Install center support.




**Snap ring**

Compress the center support and install snap ring.

**Snap ring (Reference)**

Inside diameter	mm(in.)	178 (7.01)
-----------------	---------	------------





**Snap ring**

Install the snap ring to the output shaft.

**Transfer front drive clutch**


Install the front drive clutch.






**Snap ring**

Install snap ring to the output shaft.




**Front output shaft**

Install the front output shaft to the front drive clutch.



Clean contacting surfaces of any residual packing material using gasoline or alcohol.

Apply liquid gasket ① (Loctite No. 518 or its equivalent) to the transfer chain case.




**Transfer chain case**

Install the transfer chain case to the transfer case.

Install and tighten the bolts.

Torque	kg-m(ft.lbs.)	3.5 (25.3)
--------	---------------	------------




**Sprocket and driven shaft**

Install the chain with the sprocket and driven shaft to the transfer case.






## Service Information AW30-80LE



### Snap ring

Install snap ring to the output shaft.




### Transfer chain case cover

Remove any packing material.


Clean contacting surfaces of any residual packing material using gasoline or alcohol.

Apply liquid gasket ① (Loctite No. 518 or its equivalent) to the chain cover.




Install the chain cover to the transfer case.

Torque	kg-m(ft.lbs.)	3.5 (25.3)
--------	---------------	------------



### Speedometer drive gear

Install speedometer drive gear.




### Extension housing

Clean contacting surfaces of any residual packing material using gasoline or alcohol.

Apply liquid gasket ① (Loctite No. 518 or its equivalent) to the extension housing.




## Service Information AW30-80LE



Install the extension housing to the transfer rear cover.

Torque	kg·m(ft.lbs.)	3.5 (25.3)
--------	---------------	------------




### Front companion flange

Install the washer and front companion flange to the shaft. Using special tool to hold the flange, tighten the nut.

Holding wrench : J-8614-01


Torque	kg·m(ft.lbs.)	12.5 (90)
--------	---------------	-----------

Using a hammer and punch, stake the nut.



### Companion flange


Install the companion flange in the same way as the front companion flange.



### Individual piston operation inspection

Check for the sound of operation while injecting compressed air into the oil hole indicated in the figure.


- ① : Direct clutch (C-3)
- ② : Low speed brake (B-4)
- ③ : Front direct clutch (C-4)



### Parking lock pawl bracket

Install parking lock pawl bracket to the transfer case.


Torque	kg·m(ft.lbs.)	0.7 (5.1)
--------	---------------	-----------



**No. 4 solenoid**

Install the No. 4 solenoid wire into the transfer case.  
Install the wire clamp bolt.

Torque	kg-m(ft.lbs.)	1.6 (11.6)
--------	---------------	------------




**Transfer valve body**


Install and tighten the six bolts.

Torque	kg-m(ft.lbs.)	1.00 (7.23)
--------	---------------	-------------

**Note:** Each bolt length (mm) is indicated in the figure.




Connect No. 4 solenoid connector.



**Oil pan**


Remove any packing material and be careful not to drop the oil on the contacting surfaces of the oil pan and transfer case. Clean contacting surfaces of any residual packing material using gasoline or alcohol. Apply liquid gasket ① (THREE BOND TB1281 or its equivalent) to the oil pan.



Apply seal lock adhesive (THREE BOND 1324 or its equivalent) to the four bolts.

Install the oil pan and tighten the eleven bolts.


Torque	kg-m(ft.lbs.)	0.75 (5.4)
--------	---------------	------------



**Speed sensor**

Install the speed sensor and clamp bolt.  
Connect the wiring connector.

Torque	kg·m(ft.lbs.)	0.75 (5.4)
--------	---------------	------------




**Transfer position switch**

Install the switch and wiring clamp. Tighten the mounting nut.

Torque	kg·m(ft.lbs.)	0.75 (5.4)
--------	---------------	------------

Install the shift handle.


Torque	kg·m(ft.lbs.)	1.6 (11.6)
--------	---------------	------------



**Adjust transfer position switch**

- 1) Loosen the transfer position switch bolt and set transfer shift lever to the 4H position.
- 2) Align the groove ① and 4H basic line ②.
- 3) Hold in position and tighten the bolt.


Torque	kg·m(ft.lbs.)	1.3 (9.4)
--------	---------------	-----------



**Converter housing**

Install the converter housing and tighten the bolts.

		kg·m(ft.lbs.,N·m)
Torque	M10	3.5 (25, 34)
	M12	5.8 (42, 57)



**Torque converter**

Using calipers and a straight edge, measure from the installed surface of the transmission housing.

Correct distance	mm(in.)	31 (1.02) or more
------------------	---------	-------------------




# SERVICE INFORMATION

## TOYOTA A340 TRANSMISSION SECTION


The Toyota A340 transmission has been in use from 1985 to the present in a variety of vehicles. This section will include information on the five styles of this transmission as used in the Toyota 4Runner, Pickup Truck, T100 Truck, Cressida, Supra and Lexus models. There are many differences between transmission models depending on which model vehicle they are found in especially in valve body check ball usage as well as accumulator, feed tube and filter usage which is all covered in this section. Following is a brief description and illustration of each of the five transmission models.

The **A340E** is a 4 speed electronically shifted transmission. It utilizes a lockup converter which is also electronically controlled. The transmission uses 2 shift control solenoids and 1 lockup control solenoid. Line pressure rise is controlled by a throttle cable. The A340E is used as a 2 wheel drive model.




**A340E**

The **A340F** is a 4 speed electronically shifted transmission with a mechanically controlled 4 wheel drive transfer case and an electronically controlled lockup converter clutch. This transmission also utilizes 2 shift control solenoids and 1 lockup control solenoid. Line pressure rise is controlled by a throttle cable.




**A340F**

The **A340H** is a 4 speed electronically shifted transmission with an electronically controlled 4 wheel drive automatic transfer case and an electronically controlled lockup converter clutch. The transmission utilizes 2 shift control solenoids and 1 lockup control solenoid. Line pressure rise is controlled by a throttle cable.



**A340H**


The **A341E** transmission used in **LEXUS** is a 4 speed electronically controlled transmission which utilizes an intelligent control system. The electronically controlled converter clutch is modulated for smooth operation. The transmission utilizes 4 solenoids, 2 shift control solenoids, 1 modulated lockup control solenoid and 1 modulated accumulator control solenoid for smooth shift feel. Line pressure rise is still throttle cable controlled. This transmission is used as a 2 wheel drive model.



**A341E**

The **A341E** used in 1993 and up **SUPRA** with the 2JZ-GTE engine is a 4 speed **FULLY** electronically controlled transmission with intelligent control and electronically modulated converter clutch. Line pressure rise is computer controlled. This version of the **A341E** uses 5 solenoids, 2 shift control solenoids, 1 modulated lockup control solenoid, 1 modulated accumulator control solenoid and 1 modulated pressure control solenoid.

## TOYOTA 340 SERIES VALVE BODY CHECK BALL IDENTIFICATION






- |   |  |
|---|--|
| 1. Forward Clutch Orifice Ball & Capsule                | 9. Solenoid Oil Strainer                                 |
| 2. Throttle Oil Strainer                                | 10. Torque Converter Charge<br>One Way Check Valve Ball  |
| 3. Overdrive Clutch Accumulator Feed<br>Orifice Ball    | 11. Overrun Clutch Orifice Ball                          |
| 4. Direct Clutch Accumulator Feed<br>Orifice Ball       | 12. Intermediate Band Orifice Ball                       |
| 5. Intermediate Clutch Accumulator Feed<br>Orifice Ball | 13. Valve Stopper Plate                                  |
| 6. Solenoid Oil Strainer                                | 14. Direct Clutch Orifice Ball                           |
| 7. Check Valve  | 15. Overdrive Clutch Orifice Ball                        |
| 8. Pressure Relief Valve                                | 16. Direct Clutch Accumulator Exhaust Ball               |
|   | 17. Intermediate Clutch Accumulator Exhaust Ball         |
|   | 18. Overdrive Clutch Accumulator Exhaust<br>Orifice Ball |
|   | 19. Intermediate Clutch Orifice Ball                     |
|   | 20. Low/Reverse Clutch Exhaust Orifice Ball              |
|   | *21. Direct Clutch Shuttle Ball                          |

**\*WARNING:** The use of the #21 check ball where it is not required will cause premature direct clutch failure. In order to determine whether or not the valve body requires a check ball in this location, check to see if there are 2 holes in the separator plate over the bathtub or only 1 hole. If there are 2 holes, a ball IS required. If there is 1 hole NO ball is required.

**NOTE:** Not all items listed above are used in all valve bodies. Refer to specific applications on the following 2 pages.




## A340E, F, H and A341E VALVE BODY CHECK BALL LOCATION







# Technical Service Information


## A340E, F, H and A341E VALVE BODY CHECK BALL LOCATION




## TOYOTA A340 SERIES SOLENOID IDENTIFICATION




## TOYOTA A340 SERIES SOLENOID IDENTIFICATION




## TOYOTA A340 SERIES ACCUMULATOR IDENTIFICATION




B<sub>2</sub> - Intermediate Clutch  
 C<sub>2</sub> - Direct Clutch  
 B<sub>0</sub> - Overdrive Clutch  
 C<sub>0</sub> - Overdrive Direct Clutch




EARLY 4RUNNER & TRUCK



LATE 4RUNNER & TRUCK



EARLY SUPRA







EARLY CRESSIDA



# Technical Service Information

## TOYOTA A340 SERIES ACCUMULATOR IDENTIFICATION



### Accumulator Pin Specifications

Application	Diameter In. (mm)	Height In. (mm)
<b>1988</b>		
Cressida, Supra, Pickup & 4Runner		
2nd Brake .....	.472 (11.99)	1.386 (35.20)
Direct Clutch .....	.539 (13.69)	1.307 (33.20)
<b>1989</b>		
Pickup 4WD & 4Runner 4WD (22R-E)		
2nd Brake .....	.472 (11.99)	1.386 (35.20)
Direct Brake .....	.539 (13.69)	1.307 (33.20)
<b>1990</b>		
4Runner 4WD		
2nd Brake .....	.472 (11.99)	1.386 (35.20)
Direct Brake .....	.539 (13.69)	1.307 (33.20)

### Accumulator Spring Specifications

Application	Free Length In. (mm)	Diameter In. (mm)
<b>1988</b>		
<b>A-340E</b>		
2nd Brake		
Lower		
Cressida .....	1.535 (38.99)	.748 (19.00)
Supra .....	1.496 (38.00)	.764 (19.41)
Upper		
Cressida & Supra 7M-GE ....	2.106 (53.49)	.776 (19.70)
Supra 7M-GTE .....	2.252 (57.20)	.776 (19.70)
Overdrive Brake .....	2.598 (65.99)	.626 (15.90)
Overdrive Direct Clutch		
Inner .....	1.811 (46.00)	.551 (14.00)
Outer .....	2.937 (74.60)	.799 (20.29)
Direct Clutch		
Lower .....	1.433 (36.40)	.831 (21.11)
Upper .....	1.894 (48.11)	.799 (20.29)
<b>A-340H</b>		
2nd Brake		
Lower		
.....	1.496 (38.00)	.764 (19.41)
Upper		
.....	2.106 (53.49)	.776 (19.71)

## TOYOTA A340 SERIES ACCUMULATOR SPRING IDENTIFICATION

### Accumulator Spring Specifications...continued

Application	Free Length In. (mm)	Diameter In. (mm)
<b>1988 (Cont.)</b>		
<b>A-340H</b>		
Overdrive Brake	2.744 (69.70)	.657 (16.70)
Overdrive Direct Clutch	2.638 (67.00)	.701 (17.80)
Direct Clutch		
Lower	1.535 (39.00)	.819 (20.80)
Upper (Outer)	2.008 (51.00)	.787 (20.00)
Upper (Inner)	1.264 (32.10)	.563 (14.30)
<b>1989</b>		
<b>A-340E</b>		
2nd Brake		
Cressida & Pickup 2WD	2.776 (70.50)	.776 (19.71)
Supra		
7M-GE	2.890 (73.40)	.783 (19.90)
7M-GTE	2.858 (72.60)	.783 (19.90)
Direct Clutch		
Inner		
Cressida & Supra	1.657 (42.10)	.579 (14.70)
Outer		
Cressida & Supra		
7M-GTE	2.768 (70.30)	.795 (20.20)
Supra 7M-GE	2.520 (64.00)	.795 (20.20)
Pickup 2WD	2.697 (68.50)	.795 (20.20)
Overdrive Brake		
Cressida & Supra	2.441 (62.00)	.630 (16.00)
Pickup 2WD	2.598 (66.00)	.634 (16.10)
Overdrive Direct Clutch		
Inner	1.811 (46.00)	.551 (14.00)
Outer		
Cressida & Supra	2.937 (74.60)	.823 (20.90)
Pickup 2WD	2.937 (74.60)	.799 (20.30)
<b>A-340H</b>		
2nd Brake		
Lower		
Pickup & 4Runner 22R-E	1.496 (38.00)	.764 (19.40)
4Runner 3VZ-E	.866 (22.00)	.551 (14.00)
Upper		
Pickup & 4Runner 22R-E	2.106 (53.50)	.776 (19.70)
4Runner 3VZ-E	2.776 (70.50)	.776 (19.70)
Pickup 3VZ-E	2.776 (70.50)	.776 (19.70)
Direct Clutch		
Upper (Outer)		
Pickup & 4Runner 22R-E	2.008 (51.00)	.787 (20.00)
4Runner 3VZ-E	2.697 (68.50)	.795 (20.20)
Upper (Inner)		
Pickup & 4Runner 22R-E	1.264 (32.10)	.563 (14.30)
Lower		
Pickup & 4Runner 22R-E	1.535 (39.00)	.819 (20.80)
4Runner 3VZ-E	.787 (20.00)	.476 (12.10)
Pickup 3VZ-E	2.697 (68.50)	.795 (20.20)
Overdrive Brake		
Pickup & 4Runner 22R-E	2.744 (69.70)	.657 (16.70)
Pickup & 4Runner 3VZ-E	2.598 (66.00)	.634 (16.10)
Overdrive Direct Clutch		
Inner		
Pickup & 4Runner 3VZ-E	1.811 (46.00)	.551 (14.00)
Outer		
4Runner 22R-E	2.638 (67.00)	.701 (17.80)
Pickup & 4Runner 3VZ-E	2.937 (74.60)	.799 (20.30)
Pickup 22R-E	2.638 (67.00)	.701 (17.80)

Application	Free Length In. (mm)	Diameter In. (mm)
<b>1990</b>		
<b>A-340E</b>		
2nd Brake		
Cressida, Pickup 2WD & 4Runner 2WD	2.776 (70.50)	.776 (19.70)
Supra		
7M-GE	2.890 (73.40)	.783 (19.90)
7M-GTE	2.858 (72.60)	.783 (19.90)
Direct Clutch		
Inner		
Cressida & Supra	1.657 (42.10)	.579 (14.70)
Outer		
Cressida	2.768 (70.30)	.795 (20.20)
Supra		
7M-GE	2.520 (64.00)	.795 (20.20)
7M-GTE	2.768 (70.30)	.795 (20.20)
Pickup 2WD & 4Runner 2WD	2.697 (68.50)	.795 (20.20)
Overdrive Brake		
Cressida & Supra	2.441 (62.00)	.630 (16.00)
Pickup 2WD & 4Runner 2WD	2.937 (74.60)	.634 (16.10)
Overdrive Direct Clutch		
Outer	2.937 (74.60)	.799 (20.30)
Inner	1.811 (46.00)	.551 (14.00)
<b>A-340F</b>		
2nd Brake	2.776 (70.50)	.776 (19.70)
Direct Clutch	2.698 (68.50)	.795 (20.20)
Overdrive Brake	2.744 (69.70)	.657 (16.70)
Overdrive Direct Clutch	2.638 (67.00)	.701 (17.80)
<b>A-340H</b>		
2nd Brake		
Upper		
4Runner 22R-E	2.106 (53.50)	.776 (19.70)
Lower		
4Runner 22R-E	1.496 (38.00)	.764 (19.40)
Pickup 4WD & 4Runner 3VZ-E	2.776 (70.50)	.776 (19.70)
Direct Clutch		
Upper (Outer)		
4Runner 22R-E	2.008 (51.00)	.787 (20.00)
Upper (Inner)		
4Runner 22R-E	1.264 (32.10)	.563 (14.30)
Lower		
4Runner 22R-E	1.535 (39.00)	.819 (20.80)
Pickup 4WD & 4Runner 3VZ-E	2.697 (68.50)	.795 (20.20)
Overdrive Brake		
4Runner 22R-E	2.744 (69.70)	.657 (16.70)
Pickup 4WD & 4Runner 3VZ-E	2.598 (66.00)	.634 (16.10)
Overdrive Direct Clutch		
4Runner 22R-E	2.638 (67.00)	.701 (17.80)
Outer		
Pickup 4WD & 4Runner 3VZ-E	2.937 (74.60)	.799 (20.30)
Inner		
Pickup 4WD & 4Runner 3VZ-E	1.811 (46.00)	.551 (14.00)

## TOYOTA A340 SERIES ACCUMULATOR SPRING IDENTIFICATION

Application	Free Length in. (mm)	Diameter in. (mm)
<b>1990 (Cont.)</b>		
<b>A-341E</b>		
2nd Brake .....	2.863 (75.25)	.7862 (19.970)
Direct Clutch		
Inner .....	1.575 (40.00)	.556 (14.11)
Outer .....	2.787 (70.78)	.791 (20.10)
Overdrive Brake .....	2.637 (66.97)	.639 (16.24)
Overdrive Direct Clutch .....	2.573 (65.35)	.811 (20.59)


Application ...1991 and up	Free Length in. (mm)	Diameter in. (mm)
<b>A-340E</b>		
<b>2nd Brake</b>		
Cressida, Pickup & 4Runner (2WD) .....	2.776 (70.51)	.776 (19.71)
Supra		
7M-GE .....	2.890 (73.40)	.783 (19.89)
7M-GTE .....	2.776 (70.51)	.791 (20.09)
Direct Clutch		
Inner		
Cressida, Supra, Pickup & 4Runner (2WD) .....	1.657 (42.09)	.579 (14.71)
Outer		
Cressida .....	2.768 (70.31)	.795 (20.19)
Pickup & 4Runner (2WD) .....	2.764 (70.21)	.795 (20.19)
Supra		
7M-GE .....	2.520 (64.01)	.795 (20.19)
7M-GTE .....	2.768 (70.31)	.795 (20.19)
Overdrive Brake		
Cressida, Supra		
Pickup & 4Runner (2WD) .....	2.441 (62.00)	.630 (16.00)
Overdrive Direct Clutch		
Inner .....	2.937 (74.60)	.823 (20.90)
Outer .....	1.811 (46.00)	.551 (14.00)

<b>A-340F (4-Cylinder Engine)</b>		
<b>2nd Brake</b>		
Pickup & 4Runner (4WD) .....	2.776 (70.51)	.776 (19.71)
Direct Clutch		
Pickup & 4Runner (4WD) .....	2.698 (68.53)	.795 (20.19)
Overdrive Brake		
Pickup & 4Runner (4WD) .....	2.744 (69.70)	.657 (16.69)
Overdrive Direct Clutch		
Pickup & 4Runner (4WD) .....	2.636 (67.01)	.701 (17.81)

<b>A-340H (V-6 Engine)</b>		
<b>2nd Brake</b>		
Pickup & 4Runner (4WD) .....	2.776 (70.51)	.776 (19.71)
Direct Clutch		
Inner		
Pickup & 4Runner (4WD) .....	1.657 (42.09)	.579 (14.71)
Outer		
Pickup & 4Runner (4WD) .....	2.764 (70.21)	.795 (20.19)

Application	Free Length in. (mm)	Diameter in. (mm)
<b>Overdrive Brake</b>		
Pickup & 4Runner (4WD) .....	2.441 (69.00)	.630 (16.00)
Overdrive Direct Clutch		
Inner		
Pickup & 4Runner (4WD) .....	1.811 (46.00)	.551 (14.00)
Outer		
Pickup & 4Runner (4WD) .....	2.937 (74.60)	.823 (20.90)

Application	Free Length in. (mm)	Diameter in. (mm)
<b>A-340E (Lexus SC300 &amp; SC400)</b>		
2nd Brake .....	2.776 (70.51)	.776 (19.71)
Direct Clutch		
Inner .....	1.657 (42.09)	.579 (14.71)
Outer .....	2.764 (70.21)	.795 (20.19)
Overdrive Brake .....	2.441 (62.00)	.630 (16.00)
Overdrive Direct Clutch		
Inner .....	2.937 (74.60)	.823 (20.90)
Outer .....	1.811 (46.00)	.551 (14.00)
<b>A-341E (Lexus LS400)</b>		
2nd Brake .....	2.9625 (75.250)	.7862 (19.969)
Direct Clutch		
Inner .....	1.5750 (40.005)	.5556 (14.112)
Outer .....	3.0516 (77.511)	.7910 (20.091)
Overdrive Brake .....	2.6366 (66.970)	.6394 (16.241)
Overdrive Direct Clutch		
Inner .....	1.5126 (38.420)	.5624 (14.031)
Outer .....	2.5728 (65.349)	.8106 (20.589)



**NOTE:** All accumulator spring specifications listed here have been taken from industry sources that are known for their accuracy. However, accumulator spring arrangements are subject to change by the manufacturer based on the desired shift feel that the manufacturer feels the vehicle should have. Therefore, there may be some differences between the information listed here and what you actually find in the transmission you are working on.

## TOYOTA A340 SERIES FEED TUBE & FILTER IDENTIFICATION

